


MT-SICS Interface Commands

MX and MR balances



METTLER TOLEDO

Table of Contents

1	Introduction	5
2	Command Formats	6
2.1	Conventions	6
2.2	Response formats	7
2.2.1	Format of responses with weight value	7
2.2.2	Format of responses without weight value.....	8
2.3	Error messages.....	9
2.3.1	Command-specific error messages	9
2.3.2	General error messages	10
2.4	Tips for programmers	11
2.5	Read only.....	13
3	Commands and Responses	14
	@ – Abort	14
	A10 – Nominal, +Tolerance, -Tolerance.....	15
	A35 – Identification label and value.....	16
	A36 – Result identification label and value	19
	A37 – Task identification label and value	21
	C – Cancel all commands	23
	CO – Adjustment setting	24
	C1 – Start adjustment according to current settings	26
	C3 – Start adjustment with built-in weight	27
	D – Write text to display	28
	DAT – Date	29
	DW – Show weight	30
	E01 – Current system error state	31
	I0 – Currently available MT-SICS commands	32
	I1 – MT-SICS level and level versions	33
	I2 – Device data (Type and capacity)	35
	I3 – Software version number and type definition number	36
	I4 – Serial number.....	37
	I5 – Software material number	38
	I10 – Device identification	39
	I11 – Model designation	40
	I14 – Device information.....	41
	I26 – Operating mode after restart	43
	I27 – Change history from parameter settings.....	44
	I28 – Inclination sensor state.....	45
	I33 – Approval seal break counter.....	46
	I35 – Manufacturer text array.....	47
	I36 – Approval type	48
	I37 – Scale range configuration	49
	I38 – Type label range definitions	50
	I51 – Power-on time.....	52
	I53 – Ipv4 runtime network configuration information	53
	I59 – Get initial zero information	55
	I64 – Total number of built-in weight movements.....	57
	I65 – Total operating time	58
	I66 – Total load weighed	59
	I67 – Total number of weighings.....	60
	I68 – Total backlight operating time	61
	I70 – Service provider address UTF-8	62
	I72 – Approval seal checksum.....	63
	K – Keys control.....	65

M01 – Weighing mode	67
M02 – Environment condition	68
M03 – Zero-tracking	69
M08 – Display brightness	70
M11 – Key beeper volume	71
M12 – Acoustic beep signal	72
M19 – Adjustment weight	73
M20 – Test weight	74
M21 – Unit	75
M22 – Custom unit definitions	77
M23 – Readability, 1d/xd	78
M26 – Current application	80
M27 – Adjustment history	81
M29 – Weighing value release	82
M30 – Check weighing definition	83
M69 – Ipv4 network configuration	84
M70 – Ipv4 host address and netmask for static configuration	86
M121 – Weighing chamber light brightness	88
P121 – DeltaTrac: Set plus/minus indicator	89
PW – Piece counting: Piece weight	90
PWR – Switch on / Switch off	91
R01 – Restart device	92
S – Stable weight value	93
SI – Weight value immediately	94
SIR – Weight value immediately and repeat	95
SIRU – Weight value in display unit immediately and repeat	96
SIU – Weight value in display unit immediately	97
SIUM – Weight value in display unit and MinWeigh information immediately	98
SIX1 – Current gross, net, tare values	99
SIX3 – Current gross, net, tare, HighResNet, MaxResNet values	102
SM0 – Dynamic weighing: Cancel all SMx commands	106
SM1 – Dynamic weighing: Start immediately and send the result	107
SM2 – Dynamic weighing: Start after a minimum load is exceeded send result	108
SM3 – Dynamic weighing: Start after a minimum load is exceeded, send result and repeat ..	110
SM4 – Dynamic weighing: Time interval	112
SNR – Send stable weight value and repeat on stable weight change	113
SNRU – Send stable weight value with currently displayed unit and repeat on stable weight change	115
SR – Send stable weight value and repeat on any weight change	117
SRU – Send stable weight value with currently displayed unit and repeat on any weight change	119
ST – Stable weight value on pressing (Transfer) key	121
SU – Stable weight value in display unit	122
SUM – Stable weight value in display unit and MinWeigh information	123
SXIR – Send weighing data immediately and repeat	124
T – Tare	125
TA – Tare weight value	126
TAC – Clear tare weight value	127
TI – Tare immediately	128
TIM – Time	129
TST2 – Test with external weight	130
TST3 – Test with built-in weight	132
TST4 – Repeatability test	133
UPD – Update rate of SIR and SIRU output on the host interface	134
Z – Zero	135
ZI – Zero immediately	136

4	What if...?	137
	Index	139

1 Introduction

To enable you to integrate balances into your systems in a simple way, balance functions can be accessed through an appropriate set of commands described in this document.

Additional documentation on data interface

Settings of the interface are described in the Reference Manual of the balance in question.

▶ www.mt.com/MX-RM

▶ www.mt.com/MR-RM

Data exchange with the balance

Each command received by the balance via the data interface is acknowledged by a response of the balance to the initial device. Commands and balance responses are data strings with a fixed format, and will be described in detail in the command description.

The commands that are available for your balance can be called up as a list using the [IO ▶ Page 32] command.

See also

🔗 IO – Currently available MT-SICS commands ▶ Page 32

🔗 Tips for programmers ▶ Page 11

2 Command Formats

Commands sent to the balance comprise one or more characters of the ASCII character set.

Basic rules

	Enter commands only in uppercase. Nevertheless, units have to be capitalized properly.
<code>_</code>	The possible parameters of the command must be separated from one another and from the command name by a space (ASCII 32 dec.).
<code>"text"</code>	The possible input for "text" is a sequence of characters (8-bit ASCII character set from 32 dec. to 255 dec.).
<code>..CR LF</code>	Each command must be closed by <code>C_RL_F</code> (ASCII 13 dec., 10 dec.). The characters <code>C_RL_F</code> , which can be inputted using the Enter or Return key of most entry keypads, are not listed in this description every time, but it is essential they be included for communication with the balance.

2.1 Conventions

Throughout this manual, the following conventions are used for command and response syntax:

<code>< ></code>	Triangle brackets indicate that you must specify a value for the enclosed parameter. The brackets are not sent with the command string.
<code>[]</code>	Square brackets indicate that the enclosed expression is optional and can be omitted. The brackets are not sent with the command string.
<code>a..b</code>	Intervals or ranges are represented using the "dot-dot" notation indicating the set of numbers from a to b including a and b.
<code>↓</code>	Commands sent to the balance.
<code>↑</code>	Response of the balance.

Example

Command to balance which writes **Hello** into the balance display:

<code>↓</code>	<code>D_"Hello"</code>	The quotation marks " " must be inserted in the entry.
<code>↑</code>	<code>D_A</code>	Command executed successfully.

The command terminator `CRLF` is not shown.

2.2 Response formats

All responses sent by the balance to the transmitter to acknowledge the received command have one of the following formats:

- Response with weight value
- Response without weight value
- Error message

2.2.1 Format of responses with weight value

Syntax

A general description of the response with weight value is the following.

<ID>	␣	<Status>	␣	<WeightValue>	␣	<Unit>	C _R	L _F
1-2 characters		1 character		10 characters		1-5 characters		

Parameters

Name	Type	Values	Meaning
<ID>	String		Response identification, refers to the invoking command
␣	Blank		Space (ASCII 32 dec.)
<Status>	Character	S	S table weight value
		M	Stable weight value, but below minimal weight ([SIUM ▶ Page 98] and [SUM ▶ Page 123] only)
		D	Unstable ("D" for D ynamic) weight value
		N	Unstable weight value, below minimal weight ([SIUM ▶ Page 98] and [SUM ▶ Page 123] only)
<WeightValue>	Float		Weighing result; shown as a number with 10 characters (after a blank/space!), including decimal point, and minus sign (–) directly in front of the first digit if the value is negative. The weight value appears right aligned. Preceding zeros are not shown except for the zero to the left of the decimal point. With METTLER TOLEDO DeltaRange balances, outside the fine range the last decimal place is shown as a space.
<Unit>	String		Weight unit as actually set under display unit
C _R	Byte		Carriage return (ASCII 13 dec.)
L _F	Byte		Line feed (ASCII 10 dec.)

Examples

Response with stable weight value of 14.256 g:

↓	S	Request a stable weight value
↑	S_S_____14.256_g	

Response with stable weight value of 152.38 g outside the fine range:

↓	S	Request a stable weight value
↑	S_S_____152.38_g	

2.2.2 Format of responses without weight value

Syntax

A general description of the response without weight value is the following:

<ID>	␣	<Status>	␣	Parameters...	C _R	L _F
1-5 characters		1 character				

Parameters

Name	Type	Values	Meaning
<ID>	String		Response identification, refers to the invoking command
␣	Blank		Space (ASCII 32 dec.)
<Status>	Character	A	Command executed successfully
		B	Command not yet terminated, additional responses following
Parameters...			Command-dependent response code
C _R	Byte		Carriage return (ASCII 13 dec.)
L _F	Byte		Line feed (ASCII 10 dec.)

Examples

Set the key beeper volume:

↓	M11_30	Set the key beeper volume to 30%.
↑	M11_A	Command executed successfully.

Query the actual key beeper volume:

↓	M11	Query of the current key beeper volume.
↑	M11_A_30	Current key beeper volume is set to 30%.

2.3 Error messages

2.3.1 Command-specific error messages

Syntax

A general description of the response without weight value is the following:

<ID>	␣	<Status>	C _R	L _F
1-5 characters		1 character		

Parameters

Name	Type	Values	Meaning
<ID>	String		Response identification, refers to the invoking command
␣	Blank		Space (ASCII 32 dec.)
<Status>	Character	+	Balance is in overload range (weighing range exceeded)
		-	Balance is in underload range (e.g., weighing pan is not in place)
		L	Logical error (e.g., parameter not allowed)
		I	Internal error (e.g., balance not ready yet)
C _R	Byte		Carriage return (ASCII 13 dec.)
L _F	Byte		Line feed (ASCII 10 dec.)

Example

Response while balance is in overload range:

↓	SI	Request a weight value immediately.
↑	S _L +	Overload; no weight value available.

2.3.2 General error messages

Syntax

There are three different error messages:

<ID>	C _R	L _F
2 characters		

Parameters

Name	Type	Values	Meaning
<ID>	String	ES	Syntax error: The balance has not recognized the received command or the command is not allowed
		ET	Transmission error: The balance has received a "faulty" command, e.g., owing to a parity error or interface break
		EL	Logical error: The balance can not execute the received command
C _R	Byte		Carriage return (ASCII 13 dec.)
L _F	Byte		Line feed (ASCII 10 dec.)

Example

Trial to set the key beeper volume to 30%:

↓	m11_30	m accidentally written in lowercase.
↑	ES	Syntax error; m not recognized as a command.

2.4 Tips for programmers

Overview of command of specific models

This Reference Manual covers the MT-SICS commands for balances. As the balances can differ based on model and software version, not all the MT-SICS commands are usable on every model.

i Note

We recommend using the [IO ▶ Page 32] command to get a list of all commands that are supported by your particular balance.

Example

↓	IO	Send list of commands.
↑	IO_B_0_"IO"	Level 0 command IO implemented.
↑	IO_B...	...
↑	IO_B_0_"@"	Level 0 command [@ ▶ Page 14] (abort) implemented.
↑	IO_B_1_"D"	Level 1 command D implemented.
↑	IO_B...	...
↑	IO_A_3_"SM4"	Level 3 command [SM4 ▶ Page 110] implemented.

If you need a list of commands including the version of a command, use I1 [I1 ▶ Page 33].

Command and response

You can improve the dependability of your application software by having your program evaluate the response of the balance to a command. The response is the acknowledgment that the balance has received the command.

@ – Abort

To be able to start from a determined state, when establishing the communication between balance and system, you should send an abort command to the balance, see [@ ▶ Page 14]. Otherwise, when the balance or system is switched on or off, faulty characters can be received or sent.

Sending commands without waiting for responses

Do not send multiple commands to the instrument without waiting for the corresponding responses.

If several commands are sent in succession without waiting for the corresponding responses, it is possible that the instrument confuses the sequence of command processing, or ignores entire commands, or responses are omitted.

METTLER TOLEDO DeltaRange balances

If the fine range of DeltaRange balances has been exceeded at the time of transmission, the balance sends a weight value as balance response in which the tenth character is a space.

Update rate and timeout

The update rate for repeated commands and the duration of the timeout (time-limit function) depend on the balance type, see technical data of the balance in question.

Carriage Return, Line Feed

Depending on the platform, $C_{R}L_{F}$ is not just a "new line" (Java: "newLine()" or C/C++ "\n"):

Platform	'New Line'
DOS/Windows	$C_{R}L_{F}$
Macintosh	C_{R}
Unix	L_{F}

All commands must be closed by a $C_{R}L_{F}$ (dec: 13, 10; hex: 0D, 0A).

Quotation marks ""

Quotation marks included in the command must always be entered. If a quotation mark is located within the string, it may be escaped by a backslash (\):

↓	D_"place 4\"filter!"	
↑	D_A	Balance display: place 4" filter!

Weight unit of weight value – display unit

It is always essential to consider the weight unit that is to be used to display weighing results. Depending on where the results are output, the balances offer the possibility of selecting a particular unit, see [M21 ▶ Page 75]. This enables the displayed unit and info unit to be shown on the terminal. Display unit is used to output the weighing results via an interface (host) on the basis of MT-SICS commands. The weight values and the displayed unit can only be output by means of the SU commands.

Digit [d]

A digit refers to the smallest numerical increment a balance can display – this is also referred to as the balance's readability. Example: The balance MX105 has five decimal places, its digit is 0.01 mg. The digit is sometimes used as a generic unit.

USB interface of the balance

If the Microsoft Windows® USB driver is used

Please make sure the balance will not be switched off, is not disconnected from the power and the USB cable is not disconnected during an established USB connection. Otherwise the connection is broken and can not be reestablished easily. To reestablish the connection you need to restart the PC or deactivate and reactivate the connection using the device manager.

See also

- [@ – Abort ▶ Page 14](#)
- [IO – Currently available MT-SICS commands ▶ Page 32](#)
- [I1 – MT-SICS level and level versions ▶ Page 33](#)
- [S – Stable weight value ▶ Page 93](#)
- [SI – Weight value immediately ▶ Page 94](#)
- [SIR – Weight value immediately and repeat ▶ Page 95](#)
- [SIRU – Weight value in display unit immediately and repeat ▶ Page 96](#)
- [SIU – Weight value in display unit immediately ▶ Page 97](#)
- [SR – Send stable weight value and repeat on any weight change ▶ Page 117](#)
- [ST – Stable weight value on pressing \(Transfer\) key ▶ Page 121](#)
- [SU – Stable weight value in display unit ▶ Page 122](#)
- [T – Tare ▶ Page 125](#)
- [TA – Tare weight value ▶ Page 126](#)
- [TI – Tare immediately ▶ Page 128](#)
- [Z – Zero ▶ Page 135](#)
- [ZI – Zero immediately ▶ Page 136](#)
- [C – Cancel all commands ▶ Page 23](#)

2.5 Read only

Several commands support the query but no longer the setting of a value. However, they return success for the special case of trying to set the value that is set already. The affected commands have documented this behavior in their individual descriptions.

3 Commands and Responses

@ – Abort

Description

Terminates processes such as zero, tare, calibration, or testing. If the device is in standby mode, it is turned on.

Syntax

Command

@	Resets the balance to the condition found after switching on, but without a zero setting being performed.
---	---

Response

I4_A_ "<SNR>"	Serial number is emitted; the balance is ready for operation.
---------------	---

Comments

- All commands awaiting responses are cancelled.
- Key control is set to the default setting K_{1} .
- The tare memory is not reset to zero.
- If the balance is on standby, it is switched on.
- The cancel command is always executed.
- The emitted serial number corresponds to the serial number of the terminal (if one is present), see [14 ▶ Page 37].

Example

↓	@	Abort
↑	I4_A_ "B021002593"	Balance is "reset", its serial number is B021002593.

See also

[14 – Serial number ▶ Page 37](#)

A10 – Nominal, +Tolerance, -Tolerance

Description

Use A10 to enter the nominal values, inc. +/- tolerances, or query the current values. As soon as you have specified the values, the SmartTrac changes and displays the graphic weighing-in aid.

Syntax

Commands

A10	Query of the nominal value, + tolerance, - tolerance.
A10_<No>_<Value>_<Unit>	Set the nominal value, + tolerance, - tolerance.

Responses

A10_B_0_<Value>_<Unit> A10_B_1_<Value>_<Unit> A10_A_2_<Value>_<Unit>	Query of the nominal value, + tolerance, - tolerance.
A10_A	Command understood and executed successfully.
A10_I	Command understood but currently not executable.
A10_L	Command understood but not executable.

Parameters

Name	Type	Values	Meaning
<No>	Integer	0	Nominal value
		1	+ tolerance
		2	- tolerance
<Value>	Float		Nominal value
<Unit>	String	Max 5 chars	Weight unit, % with +/- tolerances possible

Comments

- The values will be output differently depending on the application. For details on available applications and how to activate them, see [M26 ▶ Page 80].
- Specified nominal and tolerance values must be reset manually:
 - A10_0_0_g
 - A10_1_2.5_%
 - A10_2_2.5_%
- As soon as you have specified the values, the SmartTrac switches to the graphic weighing-in aid.
- Weight and percentage values are rounded, as is the case with values entered manually.

Examples

↓	A10	Query of the nominal value, + tolerance, - tolerance.
↑	A10_B_0_100.12_g	Current setting is nominal value 100.12 g, + tolerance is 5.25 g and - tolerance is 7.6%.
↑	A10_B_1_5.25_g	
↑	A10_A_2_7.6_%	
↓	A10_0_100.12_g	Set the nominal value to 100.12 g.
↑	A10_A	The nominal value is set 100.12 g.

See also

[M26 – Current application ▶ Page 80](#)

A35 – Identification label and value

Description

Use A35 to set or query the identification label, value, auto increment and input prompt to a specified application.

Syntax

Commands

A35	Query the identification label, value, auto increment and input prompt of the application.
A35_<ApplicationID>	Query the application ID of the application.
A35_<ApplicationID>_<IDNumber>	Query the application ID and ID number of the application.
A35_<ApplicationID>_<IDNumber>_<"Label">_<"Value">_<AutoIncrement>_<InputPrompt>	Set the identification label, value, auto increment and input prompt of the application.

Responses

A35_B_<ApplicationID>_<IDNumber>_<"Label">_<"Value">_ AutoIncrement_ InputPrompt A35_B... A35_A_<ApplicationID>_<IDNumber>_<"Label">_<"Value">_<AutoIncrement>_<InputPrompt>	Current identification label, value, auto increment and input prompt of the application.
A35_A	Command understood and executed successfully.
A35_L	Command understood but not executable (incorrect parameter).

Parameters

Name	Type	Values	Meaning
<ApplicationID>	Integer	0 ... max. appl.	Application identification
		0	Weighing
		1	Counting
		2	Percent
		3	Formulation
		4	Dynamic weighing A
		5	Dynamic weighing M
		7	Density
		9	DiffWeigh
		10	PipetteCheck
		11	+/-Weighing
		12	Free factor f x w
		13	Free factor f / w
		16	Weigh recall
<IDNumber>	Integer	17	Routine test
		18	Statistic
		19	Totaling
<IDNumber>	Integer	1 ... 4	Identification number within the application

Name	Type	Values	Meaning
<Label>	String	15 - 60 chars	Label of the identification (number of characters is model-dependent). The rest is cut off without warning
<Value>	String	15 - 60 chars	Value of the identification
<AutoIncrement>	Boolean	0 = disabled	Automatic increment is disabled
		1 = enabled	Automatic increment is enabled
<InputPrompt>	Boolean	0 = disabled	Input prompt is disabled
		1 = enabled	Input prompt is enabled

Comment

- Input prompt means that every time the ID is printed, the user is prompted to enter the value of the ID first.

Examples

↓	A35	Query the identification label, value, auto increment and input prompt of the application.
↑	A35_B_0_1_"Batch"_"A7_45-6"_"0_1	Application weighing, ID number 1, label "Batch", value "A7 45-6", auto increment disabled and input prompt enabled are set.
↑	A35_B_0_2_"Lot"_"CH_78-3/424"_"0_1	Application weighing, ID number 2, label "Lot", value "CH 78-3/424", auto increment disabled and input prompt enabled are set.
↑	A35_B_1_1_"Lab"_"Singapore_44-2"_"0_0	Application piece counting, ID number 1, label "Lab", value "Singapore 44-2", auto increment disabled and input prompt disabled are set.
↑	A35_B_1_2_"_"_"0_0	Application piece counting, ID number 2, no label, no value, auto increment disabled and input prompt disabled are set.
↑	A35_B_17_1_"User"_"Test2"_"0_1	Application routine test, ID number 1, label "User", value "Test2", auto increment disabled and input prompt enabled are set.
↑	A35_B_17_2_"_"_"0_0	Application routine test, ID number 2, no label, no value, auto increment disabled and input prompt disabled are set.
↑	A35_B_18_1_"User"_"Test2"_"0_1	Application statistic, ID number 1, label "User", value "Test2", auto increment disabled and input prompt enabled are set.
↑	A35_A_18_2_"_"_"0_0	Statistic application, ID number 2, no label, no value, auto increment disabled and input prompt disabled are set.
↓	A35_0	Query the identification label, value, auto increment and input prompt of the weighing application.
↑	A35_B_0_1_"Batch"_"A7_45-6"_"0_1	Application weighing, ID number 1, label "Batch", value "A7 45-6", auto increment disabled and input prompt enabled are set.
↑	A35_B_0_2_"Lot"_"CH_78-3/424"_"0_1	Application weighing, ID number 2, label "Lot", value "CH 78-3/424", auto increment disabled and input prompt enabled are set.

↑	A35_B_0_3_"Lab"_"Singapore_44-2"_"0_0	Application weighing, ID number 3, label "Lab", value "Singapore 44-2", auto increment disabled and input prompt disabled are set.
↑	A35_A_0_4_"User"_"Pnabun Kinuk"_"0_1	Weighing application, ID number 4, label "User", value "Pnabun Kinuk", auto increment disabled and input prompt enabled are set.
↓	A35_1_2	Query the identification 2 label, value, auto increment and input prompt of the piece counting application.
↑	A35_A_1_2_"Screws"_"M4"_"0_0	Piece counting application, ID number 2, label "Screws", value "M4", auto increment disabled and input prompt disabled are set.
↓	A35_1_2_"Pearls"_"C6"_"0_0	Set the identification label to "Pearls" and the value to "C6", no auto increment and no input prompt for the ID number 2 in the piece counting application.
↑	A35_A	The identification label and value are set.

A36 – Result identification label and value

Description

Use A36 to set or query the result identification label and value of currently running task.

Syntax

Commands

A36	Query the result identification label and value of the application.
A36_<IDNumber>	Query the ID number of the application.
A36_<IDNumber>_<"Label">_<"Value">	Set the result identification label and value of the application.

Responses

A36_B_<IDNumber>_<"Label">_<"Value"> A36_B.. A36_A_<IDNumber>_<"Label">_<"Value">	Current identification label and value of the application.
A36_A	Command understood and executed successfully.
A36_L	Command understood but not executable (incorrect parameter).

Parameters

Name	Type	Values	Meaning
<IDNumber>	Integer	1 ... n	Identification number within the application (n is model dependent) XPR up to 3 ID numbers are possible XSR up to 1 ID number is possible
<"Label">	String	1 - 32 chars	Label of the identification
<"Value">	String	0 - 32 chars	Value of the identification

Comments

- A sufficient number of available IDs must be configured in the UI.
- To write the ID type must be set to "manual".
- To write the label the user needs sufficient user rights. To write the value only (keeping the label the same) the user does not need any privileged user rights.
- To write the label the method must not be locked.

Examples

↓	A36	Query the result identification label and value of the application.
↑	A36_B_1_"Result_ID_1_label"_ "Result_ID_1_value"	ID number 1, label "Result ID 1 label" and value "Result ID 1 value" are set.
↑	A36_A_2_"Result_ID_2_label"_ "Result_ID_2_value"	ID number 2, label "Result ID 2 label" and value "Result ID 2 value" are set.
↓	A36_2	Query the identification labels and values of the application.
↑	A36_A_2_"Result_ID_2_label"_ "Result_ID_2_value"	Label "Result ID 2 label" and value "Result ID 2 value" are set.
↓	A36_2_"NewLabel"_ "NewValue"	Set the identification label "NewLabel" and value "NewValue" to ID number 2.

↑	A36_A	The identification label and value are set.
---	-------	---

A37 – Task identification label and value

Description

Use A37 to set or query the task identification label and value of currently running task.

Syntax

Commands

A37	Query the task identification label and value of the application.
A37_<IDNumber>	Query the ID number of the application.
A37_<IDNumber>_<"Label">_<"Value">	Set the task identification label and value of the application.

Responses

A37_B_<IDNumber>_<"Label">_<"Value"> A37_B...	Current identification label and value from the application.
A37_A_<IDNumber>_<"Label">_<"Value">	Command understood and executed successfully.
A37_L	Command understood but not executable (incorrect parameter).

Parameters

Name	Type	Values	Meaning
<IDNumber>	Integer	1 ... n	Identification number within the application (n is model dependent) XPR up to 3 ID numbers are possible XSR up to 1 ID number is possible
<"Label">	String	1 - 32 chars	Label of the identification
<"Value">	String	0 - 32 chars	Value of the identification

Comments

- A sufficient number of available IDs must be configured in the UI.
- To write the ID type must be set to "manual".
- To write the label the user needs sufficient user rights. To write the value only (keeping the label the same) the user does not need any privileged user rights.
- To write the label the method must not be locked.

Examples

↓	A37	Query the result identification label and value of the application.
↑	A37_B_1_"Result_ID_1_label"_ "Result_ID_1_value"	ID number 1, label "Task ID 1 label" and value "Task ID 1 value" are set.
↑	A37_A_2_"Result_ID_2_label"_ "Result_ID_2_value"	ID number 2, label "Task ID 2 label" and value "Task ID 2 value" are set.
↓	A37_2	Query the identification labels and values of the application.
↑	A37_A_2_"Result_ID_2_label"_ "Result_ID_2_value"	Label "Task ID 2 label" and value "Task ID 2 value" are set.
↓	A37_2_"NewLabel"_ "NewValue"	Set the identification label "NewLabel" and value "NewValue" to ID number 2.

↑	A37_A	The identification label and value are set.
---	-------	---

C – Cancel all commands

Description

Cancel all running commands.

Syntax

Command

C	Cancel running commands.
---	--------------------------

Responses

C_B	The cancel running command has been started.
C_A	Command understood and executed successfully.

Comments

- This command has a similar functionality as the command [[@](#) ▶ Page 14] but responds with a well defined answer and does not fully reset the device.
- This command is executed always immediately.
- This command cancels all active and pending interface commands correctly and in a safe way on the interface where cancel was requested. This command does not cancel any commands or procedures that are not triggered by a SICS command.
- The command C responds with C_A after all active and pending interface commands have been terminated.
- This command is typically used for repeating commands such as [[SIR](#) ▶ Page 95] and for adjustment commands triggering a procedure.
- New procedures/command requests can be initiated right after a C_A.

Example

↓	C	Cancel running commands.
↑	C_B	Cancel running started.
↑	C_A	Command understood and executed successfully.

Command-specific error responses

Response

C_E_<Error>	Current error code.
-------------	---------------------

Parameter of command-specific error

Name	Type	Values	Meaning
<Error>	Integer	0	Error while canceling

C0 – Adjustment setting

Description

This command queries and sets the type of adjustment. Additional commands are required to actually trigger and to define the weight for external adjustment.

Syntax

Commands

C0	Query of the current adjustment setting.
C0_<Mode>_<WeightType>	Set the adjustment setting.

Responses

C0_A_<Mode>_<WeightType>_<"WeightValue_ Unit">	Weight value and unit specify the value of the weight for an external adjustment requested from the user via the display, see [C1 ▶ Page 26]. The unit corresponds to the factory setting of display unit, e.g., gram (g). With internal adjustment, neither weight value nor unit appears.
C0_I	Command understood but currently not executable (balance is currently executing another command, e.g., taring).
C0_A	Adjustment setting set successfully.
C0_L	Command understood but not executable (incorrect parameter; certified version of the balance).

Parameters

Name	Type	Values	Meaning
<Mode>	Integer	0	Mode = Manual The adjustment can only be triggered manually. A change in the ambient conditions has no influence on the initiation of the calibration procedure.
		1	Mode = Auto, status display "AutoCal" or "Cal" not activated If a balance setting invokes a trigger because Mode 1 is selected, the status display "AutoCal" or "Cal" will be activated; this means the balance will ask for adjustment.
		2	Mode = Auto, status display "AutoCal" or "Cal" flashes The sensors built into the balance have determined a considerable change in the ambient conditions. The balance requests an adjustment or at least a test, see TST x commands.
<WeightType>	Integer	0	Built-in weight
		1	External weight
<"WeightValue">	String		Weight values specify the value of the weight for an external calibration requested from the user via the display or interface, see [C1 ▶ Page 26].
<"Unit">	String		The unit corresponds to the factory setting of display unit, e.g., gram (g).

Comments

- Setting `<Mode> = 1` and `<Weight> = 0` corresponds to the menu setting "ProFACT" / "FACT" under "Adjust/Test". `<Mode> = 2` can not be set.
- C2 is independent of c0.
- The value of the external weight can be changed in the menu of the balance under "Adjust/Test ", see Reference Manual or [M19 ▶ Page 73].
- Use [C1 ▶ Page 26] to start an adjustment defined with c0.
- c0 must be reset manually; [@ ▶ Page 14] has no effect.

Examples

↓	c0	Query of the current status and setting of the adjustment.
↑	C0_A_2_1_"100.000_g"	Current setting of mode is "Auto". The ambient conditions of the balance have changed so much that the balance requests an adjustment (<code><Mode> = 2</code>) with the external weight (<code><Weight> = 1</code>). The adjustment is initiated with the command [C1 ▶ Page 26] and requires a weight of 100.000 g.
↓	C0_0_1	Set adjustment setting to manual and external.
↑	C0_A	Adjustment setting set.

See also

[🔗 M19 – Adjustment weight ▶ Page 73](#)

C1 – Start adjustment according to current settings

Description

c1 is used to trigger an adjustment as defined using the c0 command.

Syntax

Command

C1	Start the adjustment according to the current setting, see [C0 ▶ Page 24].
----	--

First Responses

C1_B	The adjustment procedure has been started. Wait for second response, see Comments.
C1_I	Command understood but currently not executable (balance is currently executing another command). No further response follows.
C1_L	Command understood but not executable (e.g. approved version of the balance). No further response follows.

Further Responses

C1_<"WeightValue_Unit">	Weight request with external adjustment.
C1_A	Command understood and executed successfully.
C1_I	The adjustment was aborted as, e.g., stability not attained or the procedure was aborted with the C key.

Parameters

Name	Type	Values	Meaning
<"WeightValue">	String		Weight values specify the value of the weight for a sensitivity adjustment requested from the user via the display or interface
<"Unit">	String		The unit corresponds to the definition unit, e.g., gram (g)

Comments

- Commands sent to the balance during the adjustment operation are not processed and responded to in the appropriate manner until the adjustment is at an end.
- The value of the external adjustment weight needed for adjustment must be set accordingly by an [M19 ▶ Page 73] command.

Example

↓	C1	Start the adjustment according to the current setting.
↑	C1_B	Adjustment operation started.
↑	C1_"_____0.00_g"	Prompt to unload the balance.
↑	C1_"_____2000.00_g"	Prompt to load the adjustment weight of 2000.00 g.
↑	C1_"_____0.00_g"	Prompt to unload the balance.
↑	C1_A	Adjustment completed successfully.

See also

- [@ – Abort ▶ Page 14](#)
- [C0 – Adjustment setting ▶ Page 24](#)
- [M19 – Adjustment weight ▶ Page 73](#)

C3 – Start adjustment with built-in weight

Description

You can use `c3` to start an internal adjustment procedure.

Syntax

Command

<code>C3</code>	Start the internal adjustment.
-----------------	--------------------------------

First Responses

<code>C3_B</code>	The adjustment procedure has been started. Wait for second response.
<code>C3_I</code>	Adjustment cannot be performed at present as another operation is taking place, or the adjustment strategy is not configured correctly. No second response follows.
<code>C3_L</code>	Adjustment operation not possible (e.g., no internal weight). No second response follows.

Further Responses

<code>C3_A</code>	Adjustment has been completed successfully.
<code>C3_I</code>	The adjustment was aborted as, e.g., stability not attained or the procedure was aborted with the Cancel button on the terminal.

Comments

- Commands sent to the balance during the adjustment operation are not processed and responded to in the appropriate manner until the adjustment is at an end.
- Adjustment cannot be performed if 'External adjustment' or 'No adjustment' is configured on the instrument. Set the adjustment strategy to 'Internal adjustment'.

Example

↓	<code>C3</code>	Start the internal adjustment.
↑	<code>C3_B</code>	Adjustment operation started.
↑	<code>C3_A</code>	Adjustment completed successfully.

D – Write text to display

Description

Use `D` to write text to the balance display.

Syntax

Command

<code>D_<Text"></code>	Write text into the balance display.
------------------------------	--------------------------------------

Responses

<code>D_A</code>	Command understood and executed successfully: Text appears left-aligned in the balance display marked by a symbol, e.g., *.
<code>D_I</code>	Command understood but currently not executable.
<code>D_L</code>	Command understood but not executable (incorrect parameter or balance with no display).

Parameter

Name	Type	Values	Meaning
<code><Text></code>	String		Text on the balance display

Comments

- A symbol in the display, e.g., * indicates that the balance is not displaying a weight value.
- The maximum number of characters of "text" visible in the display depends on the balance type. If the maximum number of characters is exceeded, the text disappears on the right side.
- Quotation marks can be displayed as indicated in chapter [1.1.3 ▶ Page 12].
- Use the `DW` command to switch the main display to 'show weight' mode.

Examples

↓	<code>D_"HELLO"</code>	Write HELLO into the balance display.
↑	<code>D_A</code>	The full text HELLO appears in the balance display.
↓	<code>D_" "</code>	Clear the balance display.
↑	<code>D_A</code>	Balance display cleared, marked by a symbol, e. g., *.

See also

- [DW – Show weight ▶ Page 30](#)
- [Tips for programmers ▶ Page 12](#)

DAT – Date

Description

Set or query the balance system date.

Syntax

Commands

DAT	Query of the current date of the balance.
DAT_<Day>_<Month>_<Year>	Set the date of the balance.

Responses

DAT_A_<Day>_<Month>_<Year>	Current date of the balance.
DAT_A	Command understood and executed successfully.
DAT_I	Command understood but currently not executable (balance is currently executing another command).
DAT_L	Command understood but not executable (incorrect parameter).

Parameters

Name	Type	Values	Meaning
<Day>	Integer	01 ... 31	Day
<Month>	Integer	01 ... 12	Month
<Year>	Integer	1970 ... 2099	Year The accepted range of years is depending on platform/ product

Example

↓	DAT	Query of the current date of the balance.
↑	DAT_A_01_10_2017	The date of the balance is 1st October 2017.

See also

 TIM – Time ▶ Page 129

DW – Show weight

Description

Resets the display after using the `D` command. Then the device display shows the current weight value and unit.

Syntax

Command

DW	Switch the main display to weight mode.
----	---

Responses

DW_A	Command understood and executed successfully: Main display shows the current weight value.
DW_I	Command understood but currently not executable.

Comment

- `DW` resets the balance display following a [`D` ▶ Page 28] command.

Example

↓	DW	Switch the main display to weight mode.
↑	DW_A	Main display shows the current weight value.

See also

[D – Write text to display ▶ Page 28](#)

E01 – Current system error state

Description

This command queries severe and fatal system errors.

Syntax

Command

E01	Query of the current system error state.
-----	--

Responses

E01_<ErrorCode>_<"ErrorMessage">	Current error code and message.
E01_I	Command understood but currently not executable.

Parameters

Name	Type	Values	Meaning
<ErrorCode>	Integer	0	No error
		4	EEPROM error
		5	Wrong cell data
		6	No standard calibration
		7	Program memory defect
		9	Temperature sensor defect
		16	Wrong load cell brand
		17	Wrong type data set
		100	Memory full
		101	Battery backup lost
<"ErrorMessage">	String	128 chars	Error text message in UTF-8

Comments

- The error code and message will change as soon as the device detects an other state i.e. after a restart or reset.
- If the device is able to detect multiple error s in parallel then only the most critical error (lowest error number) is stated.

Example

I0 – Currently available MT-SICS commands

Description

The I0 command lists all commands implemented in the present software.

All commands are listed first in level then in alphabetical order - even though levels are not supported anymore the Syntax of this command hasn't changed.

Syntax

Command

I0	Send list of all implemented MT-SICS commands.
----	--

Responses

I0_B_<Level>_<"Command"> I0_B_<Level>_<"Command"> I0_B ... I0_A_<Level>_<"Command">	Number of the MT-SICS level where the command belongs to 2nd (next) command implemented. ... Last command implemented.
I0_I	Command understood but currently not executable (balance is currently executing another command).

Parameters

Name	Type	Values	Meaning
<Level>	Integer	0	MT-SICS level 0 (Basic set)
		1	MT-SICS level 1 (Elementary commands)
		2	MT-SICS level 2 (Extended command list)
		3	MT-SICS level 3 (Application specific command set)
<"Command">	String		MT-SICS command

Comment

- If I0 lists commands that cannot be found in the manual, these are reserved commands "for internal use" or "for future use", and should not be used or altered in any way.

Example

↓	I0	Send list of commands.
↑	I0_B_0_"I0"	Level 0 command I0 implemented.
↑	I0_B...	...
↑	I0_B_0_"@"	Level 0 command [@ ▶ Page 14] (abort) implemented.
↑	I0_B_1_"D"	Level 1 command D implemented.
↑	I0_B...	...
↑	I0_A_3_"SM4"	Level 3 command [SM4 ▶ Page 110] implemented.

See also

- 🔗 @ – Abort ▶ Page 14
- 🔗 C – Cancel all commands ▶ Page 23
- 🔗 SM4 – Dynamic weighing: Time interval ▶ Page 112

I1 – MT-SICS level and level versions

Description

Query MT-SICS level and versions.

Syntax

Command

I1	Query of MT-SICS level and MT-SICS versions.
----	--

Responses

I1_A_<"Level">_<"v0">_<"v1">_<"v2">_<"v3">	Current MT-SICS level and MT-SICS versions.
I1_I	Command understood but currently not executable.

Parameters

Name	Type	Values	Meaning
<Level>	String	0	MT-SICS level 0
		01	MT-SICS level 0 and 1
		012	MT-SICS level 0, 1 and 2
		03	MT-SICS level 0 and 3
		013	MT-SICS level 0, 1 and 3
		0123	MT-SICS level 0, 1, 2, and 3
		3	Device-specific with MT-SICS level 3
<"v0"> ... <"v3">	String		MT-SICS versions of the related level (0 to 3)

Comment

- The command I14 provides more comprehensive and detailed information.

Example

↓	I1	Query the current MT-SICS level and version.
↑	I1_A_"0123"_ "2.00"_ "2.20"_ "1.00"_ "1.50"	Level 0-3 is implemented and the according version numbers are shown.

Note

The idea behind the MT-SICS level was the standardization of the commands for all METTLER TOLEDO devices. With the MT-SICS levels a simple identification was created to identify a certain set of MT-SICS command (and the functionality behind); see below.

With years of experience and with MT-SICS commands and devices becoming more and more complex it is no longer possible to maintain the levels and the command behind in the original way. Thus we decided no longer to support the levels in the MT-SICS manuals. Consequently the level version for level 0, 1 and 2 needs to be fixed to a version, version of level 3 has to remain product specific.

- Level 0 fixed to version 2.30
- Level 1 fixed to version 2.22
- Level 2 fixed to version 2.33
- Level 3 is product specific and must be defined by the according product team
For Rainbow examples, Level 3 is fixed to version 2.20

Usually all defined commands at the level of 0...1 were implemented in the devices. This is no longer the case. Therefore, do not expect anymore that all commands of a certain level are implemented.

MT-SICS Levels

Since the 1980s, products launched on the market support the standardized command set "METTLER TOLEDO Standard Interface Command Set" (MT-SICS), which is divided into 4 levels, depending on the functionality of the device:

MT-SICS level 0:	Basic command set, e.g., weighing cell.
MT-SICS level 1:	Elementary command set, i.e. balances without integrated applications.
MT-SICS level 2:	Extended command, maybe set specific for a device family, e.g., for the Excellence balance line.
MT-SICS level 3:	Application-specific command set, e.g., MT-SICS for piece counting or percent weighing, dynamic weighing, etc.

Commands of MT-SICS Level 0

The following commands are assigned to MT-SICS Level 0:

@	Cancel
I0	Implemented MT-SICS commands
I1	MT-SICS level and level versions
I2	Device data
I3	Software version and type
I4	Serial number
I5	Software material number
S	Stable weight value
SI	Weight value immediately
SIR	Weight value immediately and repeat
Z	Zero
ZI	Zero Immediately

Commands of MT-SICS Level 1

The following commands are assigned to MT-SICS Level 1:

D	Write text to display
DW	Show weight
K	Key control
SR	Send stable weight value and repeat on any weight change
T	Tare
TA	Tare weight value
TAC	Clear tare weight value
TI	Tare immediately

Commands of MT-SICS Level 2

Commands extend the basic and elementary function, but not application specific, e.g.,:

C..., E..., COM, DAT, DATI, ECHO, I..., M..., P..., PWR, R..., SI..., SN..., SM..., SU..., TIM, TS..., UPD, WS, ZS

Commands of MT-SICS Level 3

Application-specific command set, e.g., MT-SICS for piece counting or percent weighing

A..., LX..., PW, SM...

See also

 I14 – Device information ► Page 41

I2 – Device data (Type and capacity)

Description

Use I2 to query the device data (type), including the weighing capacity. The response is output as a single string.

Syntax

Command

I2	Query of the balance data.
----	----------------------------

Responses

I2_A_<"text">	Balance type and capacity.
I2_I	Command understood but currently not executable (balance is currently executing another command, e.g. taring).

Parameters

Name	Type	Values	Meaning
<"Type">	String		Type of balance
<"Capacity">	String		Capacity of balance
<"Unit">	String		Weight unit

Comments

- The number of characters of "text" depends on the balance type and capacity.

Example

↓	I2	Query of the balance data.
↑	I2_A_"MS204S_220.0090_g"	Balance type and capacity.

See also

[🔗 I14 – Device information ▶ Page 41](#)

I3 – Software version number and type definition number

Description

Provides the software version number and the type definition number.

Syntax

Command

I3	Query of the balance software version and type definition number.
----	---

Responses

I3_A_<"Software_TDNR">	Balance software version and type definition number.
I3_I	Command understood but currently not executable (balance is currently executing another command, e.g. taring).

Parameters

Name	Type	Values	Meaning
<"Software TDNR">	String		Software version number and type definition number (TDNR)

Comments

- Only the software version of the terminal software is issued.
- If no terminal is present, the bridge software is issued instead.
- More detailed information is available with [I14 ▶ Page 41].

Example

↓	I3	Query of the software version number(s) and type definition number.
↑	I3_A_"2.10_10.28.0.493.142"	2.10: Software version number. 10.28.0.493.142: Type definition. number

See also

[I14 – Device information ▶ Page 41](#)

I4 – Serial number

Description

Use I4 to query the serial number of the balance terminal.

Syntax

Command

I4	Query of the serial number.
----	-----------------------------

Responses

I4_A_<"SerialNumber">	Serial number.
I4_I	Command not understood, not executable at present Command understood but currently not executable (balance is currently executing another command, e.g. initial zero setting).

Parameter

Name	Type	Values	Meaning
<"SerialNumber">	String		Serial number

- The serial number agrees with that on the model plate and is different for every balance.
- The serial number can be used, for example, as a device address in a network solution.
- The balance response to I4 appears unsolicitedly after switching on and after the abort command [[@](#) ▶ Page 14].
- More detailed information is available with [[I14](#) ▶ Page 41].
- Only the serial number of the terminal is issued.
- If no terminal is present, the serial number of the bridge is issued instead.

Example

↓	I4	Query of the serial number.
↑	I4_A_"B021002593"	The serial number is "B021002593".

See also

[@](#) – Abort ▶ Page 14

[I14](#) – Device information ▶ Page 41

I5 – Software material number

Description

Use I5 to query the software material number (SW-ID).

Syntax

Command

I5	Query of the software material number and index.
----	--

Responses

I5_A_<"Software">	Software material number and index.
I5_I	Command understood but currently not executable (balance is currently executing another command).

Parameter

Name	Type	Values	Meaning
<"Software">	String		Software material number and index

Comments

- The SW-ID is unique for every Software. It consists of an 8-digit number and an alphabetic character as an index.
- More detailed information is available with [I14 ▶ Page 41].
- Only the SW-ID of the terminal is issued.
- If no terminal is present, the SW-ID of the bridge is issued instead.

Example

↓	I5	Query of the software material number and index.
↑	I5_A_"12121306C"	12121306C: Software material number and index.

See also

[I14 – Device information ▶ Page 41](#)

I10 – Device identification

Description

Use I10 to query or define the balance identification (balance ID). This allows an individual name to be assigned to a balance.

Syntax

Commands

I10	Query of the current balance ID.
I10_<"ID">	Set the balance ID.

Responses

I10_A_<"ID">	Current balance ID.
I10_A	Command understood and executed successfully.
I10_I	Command understood but currently not executable (balance is currently executing another command).
I10_L	Command not executed as the balance ID is too long (max. 20 characters).

Parameter

Name	Type	Values	Meaning
<"ID">	String	0 ... 20 chars	Balance or weigh module identification

Comments

- A sequence of maximum 20 alphanumeric characters are possible as <ID>.
- The set balance ID is retained even after the abort command [[@](#) ▶ Page 14].

Example

↓	I10	Query of the current balance ID.
↑	I10_A_ "My_Balance"	The balance ID is "My Balance".

I11 – Model designation

Description

This command is used to output the model designation.

Syntax

Command

I11	Query of the current balance type.
-----	------------------------------------

Responses

I11_A_<"Model">	Current balance type.
I11_I	Type can not be transferred at present as another operation is taking place.

Parameter

Name	Type	Values	Meaning
<"Model">	String	Max 20 chars	Balance type

Comments

- A sequence of maximum 20 alphanumeric characters is possible as <Model>.
- The following abbreviations used in model designations are relevant to MT-SICS:
 - DR = Delta Range
 - DU = Dual Range
 - /M, /A = Approved balance

Example

↓	I11	Query of the current balance type.
↑	I11_A_"MX204"	The balance is an "MX204".

I14 – Device information

Description

This command is used to output detailed information about the device. All components – including optional accessories – are taken into account and the associated data is output.

Syntax

Command

I14	Query of the current balance information.
-----	---

Responses

I14_A_<No>_<Index>_<"Info">	Current balance information.
I14_I	Command understood but currently not executable.
I14_L	Command understood but not executable (incorrect parameter).

Parameters

Name	Type	Values	Meaning
<No>	Integer	0	Instrument configuration
		1	Instrument description
		2	SW-identification number
		3	SW version
		4	Serial number
		5	TDNR number
<Index>	Integer		Index of instrument module
<"Info">	String	<Bridge>	Weighing bridge information corresponding to <No>
		<Terminal>	Balance terminal information corresponding to <No>
		<Option>	Balance option information corresponding to <No>
		<Balance>	Balance information corresponding to <No>
		<Printer>	Printer information corresponding to <No>
		<Second Display>	Second Display information corresponding to <No>

Comments

- The response to the query of instrument configuration can comprise one or more lines (compact balances, bridges with/without terminal etc.)
- The description of an option is the language-independent product name, e.g. "RS232-Option".
- If there are several modules of the same kind, the descriptions have an appendix, comprising of a hyphen and a number. Examples: <Option-1>, <Option-2>.

Examples

↓	I14_0	Query of the current balance information.
↑	I14_A_0_1_"Balance"	"Balance".
↓	I14_1	Query of the current instrument descriptions.
↑	I14_A_1_1_"MX204DR/A01"	Balance is an "MX204DR/A01".
↓	I14_2	Query of the current software identification numbers.
↑	I14_A_2_1_"12121304A"	Software identification number of the balance is "12121304AA".
↓	I14_3	Query of the current software versions.
↑	I14_A_3_1_"1.55"	Version of the balance software is "1.55".
↓	I14_4	Query of the serial numbers.
↑	I14_A_4_1_"1123121443"	Serial number of the balance is "1123121443".
↓	I14_5	Query of the type definition numbers.
↑	I14_A_5_1_"23.28.3.1534.776"	Type definition number of the balance is "23.28.3.1534.776".
↓	I14	Query of the current instrument descriptions.
↑	I14_B_0_1_"Balance"	"Balance".
↑	I14_B_1_1_"MX204DR"	Balance is an "MX204DR".
↑	I14_B_2_1_"11670123"	Software identification number of the balance is "11670123".
↑	I14_B_3_1_"1.23"	Version of the balance software is "1.23".
↑	I14_B_4_1_"1234567890"	Serial number of the balance is "1234567890".
↑	I14_A_5_1_"1.2.3.4.5"	TDNR of the terminal is "1.2.3.4.5".

I26 – Operating mode after restart

Description

Use I26 to query the operating mode.

Syntax

Command

I26	Query of the operating mode.
-----	------------------------------

Responses

I26_A_<Mode>	Operating mode.
I26_I	Operating mode can not be transferred at present as another operation is taking place.

Parameter

Name	Type	Values	Meaning
<Mode>	Integer	0	User mode
		1	Production mode
		2	Service mode
		3	Diagnostic mode

Example

↓	I26	Query of the operating mode.
↑	I26_A_0	Operation mode is: user mode.

I27 – Change history from parameter settings

Description

Use I27 to query the change history from the parameter settings.

Syntax

Command

I27	Query the change history.
-----	---------------------------

Responses

I27_B_<No>_<Day>_<Month>_<Year>_<Hour>_<Minute>_<"Name">_<"ID">_<"What">_<"Old">_<"New"> I27_B... I27_A_<No>_<Day>_<Month>_<Year>_<Hour>_<Minute>_<"Name">_<"ID">_<"What">_<"Old">_<"New">	Get change history.
I27_A	No data, empty change history.
I27_I	Command understood but currently not executable.

Parameters

Name	Type	Values	Meaning
<No>	Integer	1 ... n	Change number (n is product dependent)
<Day>	Integer	1 ... 31	Day on which the parameter has been changed
<Month>	Integer	1 ... 12	Month on which the parameter has been changed
<Year>	Integer	2000 ... 2099	Year on which the parameter has been changed
<Hour>	Integer	0 ... 23	Hour on which the parameter has been changed
<Minute>	String	0 ... 59	Minute on which the parameter has been changed
<"Name">	String		User name
<"ID">	String		Identification
<"What">	String		Title of changed parameter
<"Old">	String		Old value
<"New">	String		New value

Example

↓	I27	Query change history.
↑	I27_B_1_12_12_2009_12_00_ "User_1" _ "1" _ "Number_of_users" _ "User_6_Off" _ "User_6_On"	Last change: Number of users -> User 6 from off to on.
↑	I27_A_2_01_12_2009_10_22_ "User_1" _ "1" _ "Passw._Change_Date" _ "Off" _ "On"	Password change date from off to on.

I28 – Inclination sensor state

Description

Indicates whether or not the vertical deviation of the device is within the permissible limits.

Syntax

Command

I28	Query the current state of inclination sensor.
-----	--

Responses

I28_A_<Status>	Current state of inclination sensor.
I28_I	The inclination sensor cannot be transferred at present as another operation is taking place or there is a failure at the inclination sensor.

Parameter

Name	Type	Values	Meaning
<Status>	Integer	0	Within the limits
		1	Outside the limits

Comments

- Also supported by stand-alone platforms. During stand-alone operation, the backlighting for the inclination sensor is not activated.
- If no inclination sensor is present, an "ES" response is generated.

Example

↓	I28	Query of the current state of the inclination sensor.
↑	I28_A_1	The vertical deviation of the device is outside the limit.

I33 – Approval seal break counter

Description

I33 returns the service counter without breaking the approval seal. The service counter is increased after a successful service calibration or service linearization.

Syntax

Command

I33	Query of the service counter.
-----	-------------------------------

Responses

I33_A_Counter	Current service counter.
I33_I	Command understood but currently not executable.

Parameter

Name	Type	Values	Meaning
<Counter>	Integer		Status of service counter

Example

↓	I33	Query of the service counter.
↑	I33_A_37	The actual service counter is 37.

I35 – Manufacturer text array

Description

This command reads the manufacturer text array by index. The text array can be used by the manufacturer for storing arbitrary data in text form. The entries are limited to 26 characters and there are 32 entries available.

Syntax

Command

I35	Query the complete manufacturer text array.
I35_Index	Query the manufacturer text array by index.

Responses

I35_B_Index_"Text" I35_B.. I35_A_Index_"Text"	Reads the parameters from the device; all entries.
I35_Index I35_A_Index_"Text"	Reads the parameters from the device; specific entry.

Parameters

Name	Type	Values	Meaning
<Index>	Unsigned 8 bits	0 ... 31	
<Text>	String	Encoding UTF-8	Maximum length is restricted to 8 – 26 chars,i.e., 26 bytes. The text is set by the manufacturer

Comment

- There is a block of 1024 bytes reserved for this data. Due to the overhead of 6 bytes per entry, the total memory of 1024 bytes is exactly consumed $[(26 + 6) * 32 = 1024]$.

Examples

↓	I35	Reads the parameters from the device; all entries.
↑	I35_B_0_"Mettler Toledo" I35_B1_" " I35_B.. I35_A_31_" "Serv. Tel: 0049 7431_11_11	This command returns always the whole array.
↓	I35_7	Reads the parameters from the device; specific entry. Text with index number 7.
↑	I35_A_7_"Next Serv. Date: 22.11.99"	Text with index number 7 is "Next Serv. Date: 22.11.99".

I36 – Approval type

Description

This command reads the type of regulation for which the scale is configured. This is just a command to read out for what type of approval the scale or load cell is configured. The configuration for an approval type is done by the set of parameters.

Syntax

Command

I36	Query the type of regulation.
-----	-------------------------------

Response

I36_A_Approval_ID	Reads the parameters from the device.
-------------------	---------------------------------------

Parameter

Name	Type	Values	Meaning
<Approval>	Unsigned 32 bits; unused as bitset		Represents the corresponding approval IDs, calculated according to the following formula: $Approval = \sum_{selectable\ ApprovalTypes} 2^{Approval\ ID}$
		0	OIML R60
		1	OIML R 76-1
		2	NTEP/NIST Handbook 44
		3	OIML R 51

Comment

- The settings of this command have influence on the SIX* commands. The approval flag of the SIX* commands is set to approved regarding the approval standard and the unit used. However not all the necessary type data settings are done by setting this command to a certain value. For example, the minimum load has to be set by an other command even if a certain approval type implies a specific value.

Example

↓	I36A	Reads the parameters from the device.
↑	I36_A_3	The device is declared to be configured for approval according to OIML R 51.

I37 – Scale range configuration

Description

Based on the settings of range change behavior, the number of ranges defined and anchor points of the fine ranges, the load cell or device can determine which range configuration is set. This command returns the range configuration defined within the load cell or device.

Syntax

Command

I37	Query the range configuration defined within the load cell or device.
-----	---

Response

I37_A_RangeID	Reads the parameters from the device.
---------------	---------------------------------------

Parameter

Name	Type	Values	Meaning
<RangeID>	Unsigned 16 bits; represents the range configuration of the scale	0	SR = Single Range
		1	DR = Dual Range (laboratory only)
		2	MR = Multiple Range
		3	MI = Multi-Interval (including Dual-Interval Industry and DeltaRange® Laboratory)

Comment

- The command is needed for the terminal to decide whether the range number has to be displayed or not:
 - MR: range number has to be displayed.
 - MI: range number is not important to display.

Examples

↓	I37	Reads the parameters from the device.
↑	I37_A_2	Answer of a MR scale
↓	I37	Reads the parameters from the device.
↑	I37_A_0	Answer of a SR scale
↓	I37	Reads the parameters from the device.
↑	I37_I_0	Answer of a scale with a non-standard configuration

I38 – Type label range definitions

Description

Use I38 to returns a set of information for each range/interval. All values are given in definition unit.

Syntax

Commands

I38	Query the information for each range/interval.
I38_Range	Query the range/interval.

Responses

I38_B_Range_Min _N Max _N D_E_Class_Unit I38_B... I38_A_Range_Min _N Max _N D_E_Class_Unit	Set the information for each range/interval.
--	--

Parameters

Name	Type	Values	Meaning
<Range>	Integer		Range/interval numbering according to OIML R76 and NTEP/NIST Handbook 44
		1	1 st range of device (range with smallest capacity)
		2	2 nd range of device range/interval
<Min _N >	String		Minimum load for this range according to OIML R76 and NTEP/NIST Handbook 44
<Max _N >	String		Nominal maximum weight for this range
<D>	String		Display step for this range
<E>	String		Approved step for this range
<Class>	String	0 ... 5	Accuracy class 0 = not approved 1 = Accuracy class I 2 = Accuracy class II 3 = Accuracy class III 4 = Accuracy class IIII 5 = Accuracy class III L only for NTEP/NIST Handbook 44 (20, section 2.20)
<Unit>	String		The unit used for this command is the definition unit

Comment

- All formatted values have the same number of decimal places as the smallest display step d.

Examples

↓	I38	Query the current information for multi range device class III and definition unit in g.
↑	I38_B_1_20.0_300.0_0.1_1.0_0_g	Range 1: 0 g to 300 g d = 0.1 g e = 1 g, not approved.
↑	I38_B_2_20.0_3000.0_1.0_1.0_0_g	Range 2: 0 g to 3000 g d = 1 g e = 1 g, not approved.
↑	I38_A_3_40.0_6000.0_2.0_2.0_0_g	Range 3: 0 g to 6000 g d = 2 g e = 2 g, not approved.

↓	I38	Query the current information for multi interval device class III and definition unit in kg.
↑	I38_B_1_____2.0_____60.0_____0.02_____0.10_1_kg	Range 1: 0 kg to 60 kg d = 0.02 kg e = 0.1 kg, accuracy class I.
↑	I38_B_2_____60.0_____300.0_____0.10_____0.10_1_kg	Range 2: 60 kg to 300 kg d = 0.1 kg e = 0.1 kg, accuracy class I.
↑	I38_A_3_____300.0_____600.0_____0.20_____0.20_1_kg	Range 3: 300 kg to 600 kg d = 0.2 kg e = 0.2 kg, accuracy class I.
↓	I38	Query the current information for multi interval device class II and definition unit in g.
↑	I38_B- _1_____0.0200_____20.0000_0.0002_____0.0010_2_g	Range 1: 0 g to 20 g d = 0.0002 g e = 0.001 g, accuracy class II.
↑	I38_B_2_____20.0000_____50.0000_____0.0005_____0.0010_2_g	Range 2: 20 g to 50 g d = 0.0005 g e = 0.001 g, accuracy class II.
↑	I38_A_3_____50.0000_____100.0000_____0.0010_____0.0010_2_g	Range 3: 50 g to 100 g d = 0.001 g e = 0.001 g, accuracy class II.
↓	I38	Query the current information for dual range device class III and definition unit in g.
↑	I38_B_1_____20_____3000_____1_1_3_g	Range 1: 0 g to 3000 g d = 1 g e = 1 g, accuracy class III.
↑	I38_A_2_____40_____6000_____2_2_3_g	Range 3: 0 g to 6000 g d = 2 g e = 2 g, accuracy class III.

I51 – Power-on time

Description

Delivers the power-on time; the period during which the device is powered including short interruptions (e.g., power, restart etc.) with negligible impact on thermal model of the device.

Syntax

Command

I51	Query of the power-on time.
-----	-----------------------------

Responses

I51_A_<Days>_<Hour>_<Minutes>_<Seconds>	Power-on time data.
I51_I	Command understood but currently not executable.

Parameters

Name	Type	Values	Meaning
<Days>	Integer	0 ... 65535	Power-on time days
<Hour>	Integer	0 ... 23	Power-on time hours
<Minutes>	Integer	0 ... 59	Power-on time minutes
<Seconds>	Integer	0 ... 59	Power-on time seconds

Comment

- The power-on time is counted as long as the device is powered and during interruptions (e.g., power, restart etc.) up to a product specific duration (typically a value in the range of 30 ... 60 seconds, product dependent). The duration is defined according various effects, e.g., the thermal model of the device. Interruptions longer than this time results in a reset of the power-on time to the initial values. Please note that there is a certain inherent variability, because the switch-off time will be recorded only every n seconds (typically 5 seconds, product dependent).
- The power-on time is not touched by a restart or reset of the device (in contrast to the run time, see I15).

Example

↓	I51	Query the power-on time data.
↑	I51_A_1456_17_3_37	The power-on time is 1456 days 17 hours 3 minutes and 37 seconds.

I53 – Ipv4 runtime network configuration information

Description

This command will return information entries for each Ipv4 based network interface that is configured in the system. The command is similar to the "ipconfig" command on Windows. The information is based on the settings that are currently operational in the network stack.

Syntax

Commands

I53	Query the runtime network configuration information.
I53_<Index>	Query the network interface index.

Responses

I53_B_<Index>_<"Name">_<State>_<"MAC">_<DHCP>_<AutoIP>_<"Host">_<"Netmask">_<"DefaultGateway">_<"DNSServer"> ... I53_B_<Index>_<"Name">_<State>_<"MAC">_<DHCP>_<AutoIP>_<"Host">_<"Netmask">_<"DefaultGateway">_<"DNSServer"> I53_A_<Index>_<"Name">_<State>_<"MAC">_<DHCP>_<AutoIP>_<"Host">_<"Netmask">_<"DefaultGateway">_<"DNSServer">	Current runtime network configuration information.
I53_A	Command understood and executed successfully.
I53_I	Command understood but currently not executable (no network interfaces present in the system).
I53_L	Command understood but not executable (no network interfaces with index "1" present in the system).

Parameters

Name	Type	Values	Meaning
<Index>	Integer	0 or n	Network interface index
		0	1 st network interface
		n	n + 1 th network interface
<"Name">	String		Name of the network interface
<State>	Integer	0 ... 2	State of the network interface
		0	Disabled (down)
		1	Enabled but media disconnected
2	Enabled and connected		
<"MAC">	String	Max 17 chars	MAC address of the network interface. Must be in format "00:00:00:00:00:00"
<DHCP>	Boolean	0 ... 1	DHCP enabled or disabled
		0	DHCP disabled
		1	DHCP enabled
<AutoIP>	Boolean	0 ... 1	AutoIP enabled or disabled
		0	AutoIP disabled
		1	AutoIP enabled
<"Host">	String	Max 15 chars	Ipv4 address (dot-decimal notation) of the device on the given network interface
<"Netmask">	String	Max 15 chars	Ipv4 netmask (dot-decimal notation) on the given network interface

Name	Type	Values	Meaning
<"DefaultGateway">	String	Max 15 chars	Ipv4 default gateway (default router) address (dot-decimal notation) on the given network interface
<"DNSServer">	String	Max 15 chars	Ipv4 address (dot-decimal notation) of the DNS (Domain Name Service) server on the given network interface

Comment

- The settings that are currently operational in the network stack either correspond to the static configuration ([M70 ▶ Page 86], M71, M72) or dynamic step (given by DHCP). The selection depends on the configuration mode ([M69 ▶ Page 84]).
- Before setting an IP configuration on a device (manually or by setting a fallback IP configuration in the DHCP case), the responsible person (e.g., from the IT department) for the network where the device will be connected to has to be contacted to work out a valid IP configuration for the device.

Examples

↓	I53	Query the runtime network configuration information.
↑	<pre>I53_B_0_"eth0"_2_ "11:22:33:44:55:66"_1_1_"10.0.0.2"_ "255.255.255.0"_10.0.0.1" "10.0.0.1" I53_B_1_"eth1"_1_ "aa:bb:cc:dd:ee:ff"_1_1_ "192.168.0.2"_255.255.255.0" "0.0.0.0"_192.168.0.1" I53_A_2_"wifi0"_0_ "aa:00:cc:11:ee:22"_1_1_ "172.24.225.100"_255.255.254.0" "172.24.225.1"_172.24.225.2"</pre>	<p>The network interface "eth0" is fully configured and operational.</p> <p>The network interface "eth1" is disconnected from the cable and no default gateway is configured.</p> <p>The network interface "wifi0" is currently disabled. All network interfaces do have DHCP and AutoIP enabled.</p>
↓	I53_1_0	Query the settings from network interfaces 1.
↑	<pre>I53_B_1_"eth1"_1_ "aa:bb:cc:dd:ee:ff"_1_1_ "192.168.0.2"_255.255.255.0" "0.0.0.0"_192.168.0.1"</pre>	<p>The network interface 1 "eth1" is disconnected from the cable and no default gateway is configured.</p>

See also

- [M69 – Ipv4 network configuration mode ▶ Page 84](#)
- [M70 – Ipv4 host address and netmask for static configuration ▶ Page 86](#)

I59 – Get initial zero information

Description

If a weighing device is starting up it is supposed to perform an initial zero operation before any weight values can be obtained from the device. If someone wants to obtain weight values before the initial zero operation has been successfully performed the device refuses to send weight values. In order to successfully perform the initial zero operation the load on the weight receptor must be within the switch on range limits. In the case where the initial zero operation can't be performed successfully the user gets no information if the switch on range limits are exceeded or not. This command is used to determine if currently an initial zero operation is in progress and if the switch on range limits are exceeded or not.

Syntax

Command

I59	Query the initial zero information.
-----	-------------------------------------

Response

I59_A_<InitZero>_<LoadState>	Current Initial information.
------------------------------	------------------------------

Parameters

Name	Type	Values	Meaning
<InitZero>	Integer	0 ... 2	Indicates whether an initial zero operation is in progress or not
		0	Undefined e.g. If initial zero operation not started
		1	Initial zero operation in progress
		2	Initial zero operation done
<LoadState>	Integer	+	Load above upper switch on range limit
		-	Load below lower switch on range limit
		S	Load within switch on range limits and stable
		D	Load within switch on range limits and unstable
		0	Undefined – If the parameter "InitZero" equals to 0 or 2 the parameter "LoadState" always equals to undefined

Comment

- If a zero value and an initial zero value have been saved with the M35 command the initial zero value is restored from the saved initial zero value. The answer in this case will be I59_A_2_0.

Examples

↓	I59	Query the initial zero information.
↑	I59_A_1_+	The initial zero operation is in progress and the load is above the upper switch on range limit.
↓	I59	Query the initial zero information.
↑	I59_A_1_-	The initial zero operation is in progress and the load is below the lower switch on range limit.
↓	I59	Query the initial zero information.
↑	I59_A_1_D	The initial zero operation is in progress, the load is within the switch on range limits and unstable.

↓	I59	Query the initial zero information.
↑	I59_A_0_0	The initial zero state is undefined.
↓	I59	Query the initial zero information.
↑	I59_A_2_0	The initial zero operation has been successfully performed.

I64 – Total number of built-in weight movements

Description

This command reads the device total number of built-in weight movements. Every built-in weight movements in all modes are counted.

Syntax

Command

I64	Query of total number of built-in weight movements.
-----	---

Responses

I64_A_<WeightMove>	Current built-in weight movements.
I64_I	Command understood but currently not executable.

Parameter

Name	Type	Values	Meaning
<WeightMove>	Integer		Number of built-in weight movements

Example

↓	I64	Query of total number of built-in weight movements.
↑	I64_A_1234	The total number of built-in weight movements is 1234.

I65 – Total operating time

Description

This command reads the device total operation time.

Syntax

Command

I65	Query of total operating time.
-----	--------------------------------

Responses

I65_A_<Day>_<Hour>	Current operating time.
I65_I	Command understood but currently not executable.

Parameters

Name	Type	Values	Meaning
<Day>	Integer		Operating time days
<Hour>	Integer	0 ... 23	Operating time hours

Comment

- Every full minute the microprocessor is running will be counted as operating time. This is also done during standby.

Example

↓	I65	Query of total operating time.
↑	I65_A_456_3	Device has been in operation for 456 days and 3 hours.

I66 – Total load weighed

Description

This command reads the device total load weighed. Every weight in all modes is counted.

Syntax

Command

I66	Query of total load weighed.
-----	------------------------------

Responses

I66_A_<TotalWeight>_<Unit>	Current total load weighed.
I66_I	Command understood but currently not executable.

Parameters

Name	Type	Values	Meaning
<TotalWeight>	Float		Total of all loads weighed in the definition unit
<Unit>	String		Definition unit

Comments

- The total load is increased every time an active MT-SICS [SNR ▶ Page 113] command with no preset value would send a stable weight.
- All values are added as absolute values.

Example

↓	I66	Query of total load weighed.
↑	I66_A_4455.41592_g	The total load weighed is 4455.41592 g.

See also

[🔗 I67 – Total number of weighings ▶ Page 60](#)

I67 – Total number of weighings

Description

This command reads the device total number of weighings. Every weighing in all modes is counted.

Syntax

Command

I67	Query of total number of weighings.
-----	-------------------------------------

Responses

I67_A_<WeighingNo>	Current number of weighings.
I67_I	Command understood but currently not executable.

Parameter

Name	Type	Values	Meaning
<WeighingNo>	Integer		Number of weighings

Comment

- The total number of weighings is increased every time an active MT-SICS [SNR ▶ Page 113] command with no preset value would send a stable weight.

Example

↓	I67	Query of total number of weighings.
↑	I67_A_1234	The total number of weighing is 1234.

See also

[I66 – Total load weighed ▶ Page 59](#)

I68 – Total backlight operating time

Description

This command reads the device total backlight operation time. Every backlight operating time in all modes is counted.

Syntax

Command

I68	Query of total backlight operating time.
-----	--

Responses

I68_A_<Day>_<Hour>	Current operating time.
I68_I	Command understood but currently not executable.

Parameters

Name	Type	Values	Meaning
<Day>	Integer		Backlight operating time days
<Hour>	Integer	0 ... 23	Backlight operating time hours

Example

↓	I68	Query of total backlight operating time.
↑	I68_A_456_3	Backlight has been in operation for 456 days and 3 hours.

I70 – Service provider address UTF-8

Description

Address and phone number of service provider. Only printable UTF-8 characters are admissible.

Syntax

Commands

I70	Request the whole list of entries.
I70_No	Request the text from line "No" only.

Responses

I70_B_0_"Text"	Text line 0
I70_B_1_"Text"	Text line 1
I70_B_2_"Text"	Text line 2
I70_B_3_"Text"	Text line 3
I70_B_4_"Text"	Text line 4
I70_B_5_"Text"	Text line 5
I70_B_6_"Text"	Text line 6
I70_A_7_"Text"	Text line 7
I70_A_No_"Text"	Text line No
I70_I	Command understood but currently not executable.

Parameters

Name	Type	Values	Meaning
<No>	Integer	0 ... 7	Text line number
<Text>	String	40 char	Service provider address information

Examples

↓	I70	Query of service provider Address UFT-8.
↑	I70_B_0_"メトラー・トレード株式会社"	Text line 0.
↑	I70_B_1_"〒102-0075"	Text line 1.
↑	I70_B_2_"東京都千代田区三番町"	Text line 2.
↑	I70_B_3_"3-8泉館三番町ビル4F"	Text line 3.
↑	I70_B_4_""	Text line 4.
↑	I70_B_5_""	Text line 5.
↑	I70_B_6_""	Text line 6.
↑	I70_A_7_""	Text line 7.
↓	I70_2	Query Text line 2.
↑	I70_A_2_"東京都千代田区三番町"	Text line 2.

I72 – Approval seal checksum

Description

With this command the weighing device provides a mean to check if the approval integrity is ensured. To prove this integrity this command considers the following approval aspects:

- Detection of hardware changes
- Detection of type data changes

In previous solutions the terminal software checked the following information for changes:

- IDNet: Software Number (identification block P) and IdentCode (identification block I)
- MT-SICS: Serial Number (XP0304) and Approval Seal Break Counter (I33/XP0323)

With the approval seal checksum the terminal can directly determine the approval state without knowing what information the cell actually uses for calculating it. This is a further encapsulation compared to previous solutions.

To generate the checksum the cell uses an algorithm to read out relevant identification numbers. Meaningful identification numbers can e.g. be the serial numbers and the production dates of the load cell and the main electronics. Also, it can be senseful to take the approval seal break counter into account in the calculation of the checksum to detect changes of type data.

Syntax

Command

I72	Reads the parameters from the device.
-----	---------------------------------------

Response

I72_A_<Checksum>	Checksum of approval-relevant data
------------------	------------------------------------

Parameter

Name	Type	Values	Meaning
<Checksum>	Unsigned hexadecimal 32 bits	<Calculated-Checksum>	See description above.

Examples

↓	I72	Query of checksum.
↑	I72_A_8B3E297E	Output of the checksum.

Comment

The approval seal checksum considers different changes that harm the approval of the weighing device. Below the relevant commands are listed for the corresponding changes for the Load Cell (LC) and the mainboard (MB) alternatively:

- Hardware changes:
 - XM1024 – PCBA Label, composite information
 - XM1025 – PCBA Label, tag-by-tag information
 - XP0304 – Serial number → compact device and weighing module
 - XP0306 – Production date → compact device and weighing module
 - XP0361 – Load cell identification
 - XP0362 – Production date → load cell
- Type data changes
 - I33 – approval seal break counter
 - XP0323 – approval seal break counter

With these commands parameters can be read out that can be used to calculate a checksum to ensure the approval integrity as mentioned above. It has to be guaranteed that a strong CRC-32 algorithm is used for the checksum generation instead of a simple XOR or similar. Future products can calculate the checksum based on other parameters.

Use case:

Configuration of a weighing device with a separate brought along service terminal. Serial number of the compensational module is reset to the same number as the serial number of the original module (XP0304). Reconnecting the weighing device to the original terminal should thus break the gauging. Since the approval seal break counter will not be the same as it was before this manipulation the approval seal checksum will differ and thus indicate the broken gauging.

K – Keys control

Description

With the `K` command, the behavior of the terminal keys may be configured: first, the `K` command controls whether a key invokes its corresponding function or not and second, it configures whether an indication of which key has been pressed or released is sent to the host interface or not.

Using this functionality, an application running on a connected system (e.g., a PC or PLC) may make use of the balance terminal to interact with the balance operator.

Syntax

Command

<code>K_<Mode></code>	Set configuration.
-----------------------------	--------------------

Responses

<code>K_A[_<FunctionID>]</code>	Command understood and executed successfully. Mode 4: Function with <code><FunctionID></code> was invoked by pressing the corresponding key and executed successfully.
<code>K_I[_<FunctionID>]</code>	Command understood but currently not executable (balance is actually in menu or input mode). Mode 4: Function with <code><FunctionID></code> by pressing the corresponding key, but it could not be successfully executed (e.g., calibration was aborted by user or a negative value was tared).
<code>K_L</code>	Command understood but not executable (incorrect or no parameter).

Additional Responses in Mode 3:





<code>K_<EventID>_<KeyID></code>	Key <code><KeyID></code> has issued an <code><EventID></code> .
--	---

Additional Responses in Mode 4:


<code>K_B_<FunctionID></code>	Function with <code><FunctionID></code> was invoked and started; the execution needs time to complete.
-------------------------------------	--

Parameters

Name	Type	Values	Meaning
<code><Mode></code>	Integer	1	Functions are executed, no indications are sent (factory setting)
		2	Functions are not executed, no indications are sent
		3	Functions are not executed, indications are sent
		4	Functions are executed, indications are sent
<code><EventID></code>	Char	R	Key was pressed and held around 2 seconds or double clicked
		C	Key was released (after being pressed shortly or for 2 seconds)

Name	Type	Values	Meaning	
<FunctionID>	Integer	0	Adjustment	
		2	Tare/re-zero	
		3	Data transfer to printing device	
		4	Enter menu	
		5	Quit menu and save parameters	
		6	Quit menu without saving	
		9	Standby (instrument can be switched on with reset command)	
		10	Switch weight unit	
<KeyID>	Integer		Indicator for pressed key	
<KeyID>	Integer	1		Switches the balance on or off
		2		Tares the balance
		3		Zeros the balance
		4		Returns from any menu level, or other window to the application home screen

- K_1 is the factory setting (default value).
- K_1 active after balance switched on and after the abort command [@ ▶ Page 14].
- Only one K mode is active at one time.
- The mapping of the key numbers on the terminal is displayed below:



Example

When a code with a press and hold is sent, new key commands will not be accepted.

↓	K_4	Set mode 4: when a key is pressed, execute the corresponding function and send the function number as a response.
↑	K_A	Command executed successfully.
↑	K_B_2	The taring function has been started → taring active.
↑	K_A_2	Taring completed successfully.
↑	K_B_2	The taring function has been started → taring active.
↑	K_I_2	Taring not completed successfully, taring aborted (e.g. tried to tare a negative value).

M01 – Weighing mode

Description

Use M01 to set the weighing mode or query the current setting.

Syntax

Commands

M01	Query of the current weighing mode.
M01_<WeighingMode>	Set the weighing mode.

Responses

M01_A_<WeighingMode>	Current weighing mode.
M01_A	Command understood and executed successfully.
M01_I	Command understood but currently not executable.
M01_L	Command understood but not executable (incorrect parameter).

Parameter

Name	Type	Values	Meaning
<WeighingMode>	Integer	0	Normal weighing mode
		1	Sensor mode

Comment

- Check possible settings with product-specific Reference Manual.

Example

↓	M01	Query of the current weighing mode.
↑	M01_A_1	Sensor mode is set.

M02 – Environment condition

Description

Use M02 to adjust the balance so that it is optimized for the local ambient conditions, or to query the current value.

Syntax

Commands

M02	Query of the current environment.
M02_<Environment>	Set the environment.

Responses

M02_A_<Environment>	Current environment.
M02_A	Command understood and executed successfully.
M02_I	Command understood but currently not executable.
M02_L	Command understood but not executable (incorrect parameter).

Parameters

Name	Type	Values	Meaning
<Environment>	Integer	1	Stable
		2	Standard
		3	Unstable
		4	Very unstable

Example

↓	M02_3	Set the environment to unstable.
↑	M02_A	Environment is set.

M03 – Zero-tracking

Description

Use M03 to switch the zero-tracking function on or off. M03 also serves to query the status of the zero-tracking function.

Syntax

Commands

M03	Query current status of the zero-tracking function.
M03_<AutoZero>	Set the zero-tracking function.

Responses

M03_A_<AutoZero>	Current zero-tracking function
M03_A	Command understood and executed successfully.
M03_I	Command understood but currently not executable.
M03_L	Command understood but not executable (incorrect parameter).

Parameter

Name	Type	Values	Meaning
<AutoZero>	Integer	0	Zero-tracking is switched off (is not supported by approved balances).
		1	Zero-tracking is switched on.

Example

↓	M03_1	Switch on the zero-tracking function.
↑	M03_A	The zero-tracking function is activated.

M08 – Display brightness

Description

You can use M08 to set the brightness of the terminal display or query the current setting.

Syntax

Commands

M08	Query of the current display brightness.
M08_<Brightness>	Set the display brightness.

Responses

M08_A_<Brightness>	Current display brightness.
M08_A	Command understood and executed successfully.
M08_I	Command understood but currently not executable.
M08_L	Command understood but not executable (incorrect parameter).

Comment

- The parameter setting will be saved and the only way to reset the default value will be via MT-SICS or by means of a balance user reset, see M38.

Examples

↓	M08	Query of the current display brightness.
↑	M08_A_60	The display brightness is 60%.
↓	M08_55	Set the display brightness to 55%.
↑	M08_A	The display brightness is set to 55%.

M11 – Key beeper volume

Description

Use M11 to set the volume of the key beeper or query the current setting.

Syntax

Commands

M11	Query of the current beeper volume.
M11_<BeeperVolume>	Set the beeper volume.

Responses

M11_A_<BeeperVolume>	Current key beeper volume.
M11_A	Command understood and executed successfully.
M11_I	Command understood but currently not executable.
M11_L	Command understood but not executable (incorrect parameter).

Parameter

Name	Type	Values	Meaning
<BeeperVolume>	Integer	0 ... 100	Key beeper volume in %

Comment

- The parameter setting will be saved. The only way to reset the default value will be via MT-SICS or by means of a balance user reset.

Examples

↓	M11	Query of the current key beeper volume.
↑	M11_A_60	The key beeper volume is 60%.
↓	M11_80	Set the key beeper volume to 80%.
↑	M11_A	The key beeper volume is set to 80%.

See also

[M12 – Acoustic beep signal](#) ▶ Page 72

M12 – Acoustic beep signal

Description

This command triggers an acoustic beep signal.

Syntax

Command

M12_<BeeperVariant>	Trigger the acoustic beep signal.
---------------------	-----------------------------------

Responses

M12_A	Command understood and executed successfully.
M12_I	Command understood but currently not executable.
M12_L	Command understood but not executable (incorrect parameter).

Parameters

Name	Type	Values	Meaning
<BeeperVariant>	Integer	0	Beep variant 1 (e.g. 1x beep)
		1	Beep variant 2 (e.g. high sound)
		2	Beep variant 3 (e.g. deep sound)

Comment

- You can set the volume of the beeper using [M11 ▶ Page 71]. However, this setting will not necessarily work on all balances.

Example

↓	M12_1	Trigger a beep variant 2.
↑	M12_A	Beep has been triggered.

See also

[M11 – Key beeper volume ▶ Page 71](#)

M19 – Adjustment weight

Description

Use M19 to set your external adjustment weight, or to query the current weight value and unit.

Syntax

Commands

M19	Query of the current adjustment weight.
M19_<Value>_<Unit>	Set the adjustment weight.

Responses

M19_A_<Value>_<Unit>	Current adjustment weight.
M19_A	Command understood and executed successfully.
M19_I	Command understood but currently not executable.
M19_L	Command understood but not executable (incorrect parameter) or adjustment weight is too low.

Parameters

Name	Type	Values	Meaning
<Value>	Float		Value of the adjustment weight, balance specific limitation
<Unit>	String		Weight unit of the adjustment weight = defined unit of the balance

Comments

- The adjustment weight must be entered in the defined unit of the balance. This unit can be found by entering a query command M19 without arguments.
- The taring range is specified to the balance type.
- The lower limit of the adjustment weight set with M19 is the lowest possible adjustment weight (I54_Min).
- Use C2 to begin the adjustment procedure with the set weight.
- Before a custom unit can be selected with M21, it must be set with M22.

Examples

↓	M19	Query of the current adjustment weight.
↑	M19_A_100.123_g	The adjustment weight is 100.123 g.
↓	M19_500.015_g	Set the adjustment weight to 500.015 g.
↑	M19_A	The adjustment weight is set to 500.015 g.

See also

[C0 – Adjustment setting](#) ▶ Page 24

[C1 – Start adjustment according to current settings](#) ▶ Page 26

M20 – Test weight

Description

You can use M20 to define your external test weight or query the currently weight setting.

Syntax

Commands

M20	Query of the current external test weight.
M20_<TestWeight>_<Unit>	Set the external test weight.

Responses

M20_A_<TestWeight>_<Unit>	Current external test weight.
M20_A	Command understood and executed successfully.
M20_I	Command understood but currently not executable.
M20_L	Command understood but not executable (incorrect parameter).

Parameters

Name	Type	Values	Meaning
<TestWeight>	Float		Value of the external test weight
<Unit>	String		Weight unit of the external test weight = defined unit of the balance

Comments

- The test weight must be entered in the defined unit of the balance. This unit can be found by entering a query command M20 without arguments.
- Use [TST2 ▶ Page 130] to begin the test procedure with the set weight.

Examples

↓	M20	Query of the current external test weight.
↑	M20_A_100.123_g	The external test weight is 100.123 g.
↓	M20_500.015_g	Set the external test weight to 500.015 g.
↑	M20_A	The external test weight is set to 500.015 g.

See also

[🔗 TST2 – Test with external weight ▶ Page 130](#)

M21 – Unit

Description

Use M21 to set the required weighing unit for the output channels of the weight or request current setting.

Syntax

Commands

M21	Query the unit of all output channels.
M21_<Channel>	Query the unit of output channel only.
M21_<Channel>_<Unit>	Set the unit of an output channel.

Responses

M21_B_<Channel>_<Unit>	Current first unit.
M21_B...	...
M21_A_<Channel>_<Unit>	Current last unit.
M21_<Channel>_<Unit>	Unit of output channel.
M21_A	Command understood and executed successfully.
M21_I	Command understood but currently not executable.
M21_L	Command understood but not executable (incorrect parameter).

Comments

- All s commands (except su) are given in Host unit according to the definition of the MT-SICS. Only weight units are accepted as host unit, see table above, in column applicable for definition unit marked with 'yes'.
- In the event of a power failure or restart, the display unit and info unit settings are reconfigured according to the menu settings.
- At startup the MT-SICS unit and the display unit are set according to the display unit menu setting.
- It is not possible to use "no unit" for the displayed unit.

Examples

↓	M21	Query of the current unit.
↑	M21_B_0_0 M21_B_1_0 M21_B_2_0 M21_A_3_0	Current MT-SICS unit is g. Current display unit is g. Current display unit is g. Current info unit is g.
↓	M21_0_1	Set the unit to 1 kg.
↑	M21_A	The unit is set to 1 kg.

See also

[🔗](#) SU – Stable weight value in display unit ▶ Page 122

M22 – Custom unit definitions

Description

You can use M22 to set your own custom unit or query the currently defined custom unit.

Syntax

Commands

M22	Query of the current custom unit definitions.
M22_<No>_<Formula>_<Factor>_<Unit>_<Rounding>	Set the custom unit(s).

Responses

M22_B_<No>_<Formula>_<Factor>_<Unit>_<Rounding> M22_B.. M22_A_<No>_<Formula>_<Factor>_<Unit>_<Rounding>	Current first custom unit. ... Current last custom unit.
M22_A	Command understood and executed successfully.
M22_I	Command understood but currently not executable.
M22_L	Command understood but not executable (incorrect parameter).

Parameters

Name	Type	Values	Meaning
<No>	Integer	1 ... 2	Custom display unit .. info unit
<Formula>	Integer	0 1	(net weight) x factor factor/(net weight)
<Factor>	Float		Factor
<Unit>	String	""	Unit name
<Rounding>	Float		Rounding step

Comments

- The lower limit of the adjustment weight set with M19 is the lowest possible adjustment weight (I54_Min).
- Use C2 to begin the adjustment procedure with the set weight.
- Before a custom unit can be selected with M21, it must be set with M22.

Example

↓	M22	Query of the current custom unit definitions.
↑	M22_A_1_0_15.5_""_0.05	The custom unit is (net weight) x 15.5, rounded to 0.05.

See also

[M21 – Unit](#) ▶ Page 75

M23 – Readability, 1d/xd

Description

Use M23 to set how many digits of the weighing result should be displayed or output and whether the value should be rounded, or to query the current value setting.

Syntax

Commands

M23	Query of the current readability.
M23_<Readability>	Set the readability.

Responses

M23_A_<Readability>	Current readability.
M23_A	Command understood and executed successfully.
M23_I	Command understood but currently not executable.
M23_L	Command understood but not executable (incorrect parameter).

Parameters

Name	Type	Values	Meaning
<Readability>	Integer	0	1d
		1	10d
		2	100d
		3	1000d
		4	2d
		5	5d

Comments

- It is the balance model that determines which parameters can be changed.
- The custom unit [M22 ▶ Page 77] will not be changed with the M23 command.
- M23 has no influence of the stability criteria for the [taring ▶ Page 125] and [zeroing ▶ Page 135] commands.
- The readability is specified in digits [d] – this is the smallest increment a balance may display.
- The parameter setting will be saved and the only way to set the default behavior is sent MT-SICS command M23_0 not [@ ▶ Page 14].
- If the resulting display step has an unusual value it is changed to the nearest normal display step (1, 2, 5 etc.).
Example: d = 0.02 g, readability = 2d, the resulting display step would be 0.04 g which is changed to 0.05 g.
- The readability reduction is applied to the display step of the finest range. The steps of the coarser ranges are only adapted if they would be smaller than the step of the finest range. Example:

	1d	5d	10d
Fine range resolution	0.1 g	0.5 g	1 g
Coarse range resolution	0.5 g	0.5 g	1 g

Example

↓	M23	Query the readability.
↑	M23_A_4	The readability is 2d.
↓	M23_1	Set the readability to 10d.

↑	M23_A	The readability is set to 10d.
---	-------	--------------------------------

M26 – Current application

Description

Use M26 to select the required application or query the current selection.

Syntax

Commands

M26	Query of the current application selection.
M26_<ApplicationID>	Set the application number.

Responses

M26_A_<ApplicationID>	Current application selection.
M26_A	Command understood and executed successfully.
M26_I	Command understood but currently not executable.
M26_L	Command understood but not executable (incorrect parameter).

Parameter

Name	Type	Values	Meaning
<ApplicationID>	Integer	0 ... max. appl.	Application number

Comment

- Application number: Number of the application according to the application list.

Examples

↓	M26	Query of the current application.
↑	M26_A_2	The application is Percent.
↓	M26_3	Set the application number 3.
↑	M26_A	Application 3 is set.

M27 – Adjustment history

Description

Use M27 to call up the adjustment history.

Syntax

Command

M27	Query of the adjustment history.
-----	----------------------------------

Responses

M27_B_<No>_<Day>_<Month>_<Year>_<Hour>_<Minute>_<Mode>_<"Wgt"> M27_B... M27_A_<No>_<Day>_<Month>_<Year>_<Hour>_<Minute>_<Mode>_<"Wgt">	1 st adjustment entry. ... last adjustment entry.
M27_I	Command understood but currently not executable.
M27_L	Command understood but not executable (incorrect parameter).

Parameters

Name	Type	Values	Meaning
<No>	Integer	1 ... n	Number of the adjustment entry (n is product dependent)
<Day>	Integer	1 ... 31	Date, day
<Month>	Integer	1 ... 12	Date, month
<Year>	Integer	1970 ... 2099	Date, year The accepted range of years is depending on platform/product
<Hour>	Integer	0 ... 23	Time, hour
<Minute>	Integer	0 ... 59	Time, minute
<Mode>	Integer	0	Built-in adjustment
		1	External adjustment
<"Wgt">	String		Weight of the adjustment weight used

Example

↓	M27	Query of the adjustment history.
↑	M27_B_1_1_1_2011_08_26_0_""	1 st adjustment, performed at 1.1.2011, 08:26 h, internal adjustment.
↑	M27_B_2_14_12_2010_14_30_1_ "200.1234_g"	2 nd adjustment, performed at 14.12.2010, 14.30 h, external adjustment, weight 200.1234 g.
↑	M27_A_3_14_12_2010_8_26_1_ "200.1234_g"	3 rd adjustment, performed at 14.12.2010, 08:26 h, external adjustment, weight 200.1234 g.

M29 – Weighing value release

Description

Use M29 to define the weight value release or query the current setting.

Syntax

Commands

M29	Query of the current value release setting.
M29_<ValueRelease>	Set the value release.

Responses

M29_A_<ValueRelease>	Current value release.
M29_A	Command understood and executed successfully.
M29_I	Command understood but currently not executable.
M29_L	Command understood but not executable (incorrect parameter).

Parameters

Name	Type	Values	Meaning
<ValueRelease>	Integer	0	Very fast
		1	Fast
		2	Reliable and fast
		3	Reliable
		4	Very reliable

Comment

- Not all balances offer the complete range of settings. If a setting is made that is not supported by the balance, an error message is issued (M29_L).

Example

↓	M29_3	Set the value release to reliable.
↑	M29_A	The value release is set to reliable.

M30 – Check weighing definition

Description

Use M30 to set the check weighing definition with nominal and tolerance.

Syntax

Commands

M30	Query of check weighing parameters.
M30_<Nom>_<Unit>_<Tol>	Set check weighing parameters.

Responses

M30_A_<Nom>_<Unit>_<Tol>	Check weighing parameters.
M30_A	Command understood and executed successfully.
M30_I	Command understood but currently not executable.
M30_L	Command understood but not executable (incorrect parameter, value range, ...).

Parameters

Name	Type	Values	Meaning
<Nom>	Integer	1 digit - max. load	Nominal weight
<Unit>	String		Unit of nominal weight
<Tol>	Integer		+/- tolerance in % (of nominal weight)

Examples

↓	M30	Query of check weighing parameters.
↑	M30_12.5_g_2.5	Check weighing with nominal weight 12.5 g and a tolerance of 2.5% set.
↓	M30_175.2_g_4.0	Set the check weighing definition to 175.2 g and a tolerance of 4.0%.
↑	M30_A	Check weighing definition to 175.2 g and tolerance of 4.0% is set.

M69 – Ipv4 network configuration mode

Description

General introduction: see [I53 – Ipv4 runtime network configuration information ▶ Page 53]. This specific command will set the mode of how the device will obtain an IP configuration. In case of the mode “Use DHCP, set fallback IP configuration manually”, the IP settings made via the M70 command will be used in case of problems with the DHCP server.

Use M69 to set or query the configuration but does not apply the setting immediately and does not check whether the network stack can support the selected setting. The behavior if the supplied configuration cannot be supported by the network stack is product specific. Example: If DHCP is activated by M69 although DHCP is not supported by the network stack: use a well-known hard-coded IP address.

Syntax

Commands

M69	Query the network configuration mode.
M69_<Index>	Query the network interface index.
M69_<Index>_<Mode>	Set the IP configuration mode for a given network interface.

Responses

M69_B_<Index>_<Mode> M69_B... M69_A_<Index>_<Mode>	Current network configuration mode.
M69_A	Command understood and executed successfully.
M69_I	Command understood but currently not executable (no network interfaces present in the system).
M69_L	Command understood but not executable (no network interfaces with index 0 present in the system).

Parameters

Name	Type	Values	Meaning
<Index>	Integer	0 or n	Network interface index
		0	1 st network interface
		n	n + 1 th network interface
<Mode>	Integer	0 ... 3	Mode of the IP configuration
		0	Static IP configuration
		1	Use DHCP, obtain fallback IP configuration with AutoIP
		2	Use DHCP, set fallback IP configuration manually
		3	IP networking disabled, no communication possible

Examples

↓	M69	Query the network configuration mode.
↑	M69_B_0_0 M69_B_1_1 M69_A_2_2	The network interface at index 0 is manually configured. The network interface at index 1 is configured for DHCP/AutoIP. The network interface at index 2 is configured for DHCP/Manual.
↓	M69_1	Query the mode of network interface index 1.

↑	M69_A_1_1	The network interface at index 1 is configured for DHCP/StaticIP.
↓	M69_0_0	Set IP configuration mode of network interface index 0 to manual.
↑	M69_A	The IP configuration mode at index 0 is configured for manual.
↓	M69_0_1	Set IP configuration of network interface index 0 to DHCP/StaticIP.
↑	M69_A	The IP configuration mode at index 0 is configured for DHCP/StaticIP.
↓	M69_0_2	Set IP configuration of network interface index 0 to DHCP/Manual.
↑	M69_A	The IP configuration at index 0 is configured for DHCP/Manual.
↓	M69_0_3	Set IP configuration of network interface index 0 to not configured.
↑	M69_A	The IP configuration at index 0 is not configured.

See also

 [M70 – ipv4 host address and netmask for static configuration](#) ▶ Page 86

M70 – Ipv4 host address and netmask for static configuration

Description

General Introduction: see [I53 – Ipv4 runtime network configuration information ▶ Page 53]. This specific command will set a basic IP configuration composed of IPv4 host address and IPv4 netmask address. This configuration will be used by a network device if either the configuration mode M69 is set to manual or the configuration mode is set to DHCP with manual fallback IP configuration.

Syntax

Commands

M70	Query the host address and netmask.
M70_<Index>	Query the host address and netmask of network interface index.
M70_<Index>_<"Host">_<"Netmask">	Set the host address and netmask for a given network interface.

Responses

M70_B_<Index>_<"Host">_<"Netmask"> M70_B_... M70_A_<Index>_<"Host">_<"Netmask">	Current host address and netmask.
M70_A	Command understood and executed successfully.
M70_I	Command understood but currently not executable (no network interfaces present in the system).
M70_L	Command understood but not executable (no network interfaces with index 0 present in the system).

Parameters

Name	Type	Values	Meaning
<Index>	Integer	0 or n	Network interface index
		0	1 st network interface
		n	n + 1 th network interface
<"Host">	String	Max 15 chars	Ipv4 address (dot-decimal notation) of the device on the given network interface
<"Netmask">	String	Max 15 chars	Ipv4 netmask (dot-decimal notation) on the given network interface

Comments

- If the mode of the IP configuration is set to "DHCP/Manual" M69, the setting of this command only takes effect in the network stack if DHCP fails.
- If the mode of the IP configuration is set to "DHCP/AutoIP" or "not configured" M69, this setting does not take effect in the network stack.
- Use [I53 ▶ Page 53] to read the settings that are effectively operational in the network stack. I53 will either return the configured static settings or the dynamic settings given by DHCP.

Examples

↓	M70	Query the host address and netmask.
↑	M70_B_0_"10.0.0.3"_<"255.255.255.0"> M70_B_1_"192.168.0.11"_<"255.254.0"> M70_A_2_"10.0.1.100"_<"255.255.255.0">	The host address at index 0 is "10.0.0.3" and the netmask is "255.255.255.0". The host address at index 1 is "192.168.0.11" and the netmask is "255.254.0". The host address at index 2 is set to "10.0.1.100" and the netmask is set to "255.255.255.0".

↓	M70_1	Query the host address and netmask of network interface index 1.
↑	M70_A_1_"192.168.0.11"_"255.255.255.0"	The host address at index 1 is "192.168.0.11" and the netmask is "255.255.255.0".

See also

[I53 – Ipv4 runtime network configuration information](#) ▶ Page 53

[M69 – Ipv4 network configuration mode](#) ▶ Page 84

M121 – Weighing chamber light brightness

Description

Queries or sets the current weighing chamber light brightness.

Syntax

Commands

M121	Reads the parameter from the device.
M121_<Brightness>	Writes the parameter to the device.

Responses

M121_A_<Brightness>	Indication of the current brightness level.
M121_A	Set value of brightness level.

Parameter

Name	Type	Values	Meaning
<Brightness>	Integer (unsigned 8 bits)	0 ... 100	Weighing chamber light brightness in %

Comment

XU0020 is used to test the weighing chamber light, but XU0020 does not determine an initial value.

Initial values

The initial values are hard-coded and product specific. In the example below the product uses 80 %.

↓	M121	Reads the parameter from the device.
↑	M121_A_80	The current brightness level of the weighing chamber light is 80 %.

Examples

↓	M121_1	Reads the parameter from the device.
↑	M121_A_95	The current brightness level of the weighing chamber light is 80 %.
↓	M121_55	Writes the parameter to the device.
↑	M121_A	The current brightness level of the weighing chamber has been set to the value just entered.

P121 – DeltaTrac: Set plus/minus indicator

Description

Use P121 to set the DeltaTrac plus/minus indicator.

Syntax

Commands

P121_<Target>_<Unit>	Configure DeltaTrac plus/minus indicator with default tolerance value ($\pm 2.5\%$).
P121_<Target>_<Unit>_<Tol+>_<Unit>	Configure DeltaTrac plus/minus indicator with same plus/minus tolerance.
P121_<Target>_<Unit>_<Tol+>_<Unit>_<Tol->_<Unit>	Configure DeltaTrac plus/minus indicator.

Responses

P121_A	Command understood and executed successfully.
P121_I	Command understood but currently not executable.
P121_L	Command understood but not executable (e.g. printer is not connected).

Parameters

Name	Type	Values	Meaning
<Target>	Float		Target value
<Unit>	String		Unit, only available units permitted
<Tol+><Tol->	Float		Tolerance value

Comments

- Default value is $\pm 2.5\%$.
- Only allowed units are permitted, **see** [M21 ▶ Page 75].

Examples

↓	P121_100_g_10_g_20_g	Set DeltaTrac to 100 g plus 10 g minus 20 g.
↑	P121_A	Command understood and executed successfully.
↓	P121_10_kg_100_g	Set DeltaTrac to 10 kg plus/minus 100 g.
↑	P121_A	Command understood and executed successfully.
↓	P121_350_g	Set DeltaTrac to 350 g plus/minus 2.5%.
↑	P121_A	Command understood and executed successfully.

PW – Piece counting: Piece weight

Description

Use `PW` to set the reference weight of 1 piece, which you can then use for the piece counting application.

Syntax

Commands

<code>PW</code>	Query of the piece weight for the piece counting application.
<code>PW_<SinglePiece>_<Unit></code>	Set the piece weight for the according value. The unit should correspond to the unit actually set under display unit.

Responses

<code>PW_A_<SinglePiece>_<Unit></code>	Current piece weight value in unit actually set under display unit.
<code>PW_A</code>	Command understood and executed successfully.
<code>PW_I</code>	Command understood but currently not executable (e.g., piece counting application is not active or balance is currently executing another command).
<code>PW_L</code>	Command understood but not executable (parameter is incorrect).

Comments

- By setting a reference weight, the display unit is automatically switched to unit "PCS".
- On the interface the unit is not changed. However, the piece counting value can be requested by using the [S ▶ Page 93] commands in display unit such as [SU ▶ Page 122], [SIU ▶ Page 97], after the piece weight reference has been set by `PW`.
- To change the unit of the interface to pieces, use the command [M21 ▶ Page 75].

Example

↓	<code>PW_20.00_g</code>	Set the piece weight of the piece counting application to 20.00 g.
↑	<code>PW_A</code>	Piece weight value is set.

See also

- [M21 – Unit ▶ Page 75](#)
- [SU – Stable weight value in display unit ▶ Page 122](#)
- [SIU – Weight value in display unit immediately ▶ Page 97](#)

PWR – Switch on / Switch off

Description

Use `PWR` to switch the balance on or off. When it is switched off, standby mode is activated.

Syntax

Command

<code>PWR_<OnOff></code>	Switch the balance on or off.
--------------------------------	-------------------------------

Responses

<code>PWR_A</code>	Balance has been switched off successfully.
<code>PWR_A</code> <code>I4_A_<"SNR"></code>	Balance with the serial number "SNR" has been switched on successfully see [I4 ▶ Page 37].
<code>PWR_I</code>	Command understood but currently not executable (balance is currently executing another command, e.g., taring, or application is not in Home screen).
<code>PWR_L</code>	Command understood but not executable.

Parameter

Name	Type	Values	Meaning
<code><OnOff></code>	Integer	0	Set the balance to standby mode
		1	Switch the balance on

Comments

- The balance response to [I4 ▶ Page 37] appears unsolicited after switching the balance on.
- In case of cable power driven devices, the switch off command set the device in the standby state.
- In case of cable power and battery driven devices:
 - If the device is cable powered, the switch off command `PWR_0` set the device in the standby state.
 - If the device is battery powered, the switch off command `PWR_0` set the device in the off state.

Example

↓	<code>PWR_1</code>	Switch the balance on.
↑	<code>PWR_A</code>	The balance has been switched on successfully.
↑	<code>I4_A_"0123456789"</code>	The serial number is shown.

See also

[I4 – Serial number ▶ Page 37](#)

R01 – Restart device

Description

Restarts the device. This is a warm start.

Syntax

Command

R01	Restart the device.
-----	---------------------

Response

I4_A_<"SerialNumber"> (or equivalent startup response)	Startup response of the device.
--	---------------------------------

Parameter

Name	Type	Values	Meaning
I4_A_<"SerialNumber">			Startup response after the device has restarted

Comments

- If the mapping of the serial interface is 'MT-SICS Printer 24': Command R01 response ---- METTLER TOLEDO ---- the software has been restarted.
- This command must not be confused with M38. M38 modifies parameters whereas R01 does not.

Example

↓	R01	Restart the device.
↑	I4_A_"B001000001"	The software has been restarted. The serial number of the device is B001000001.

S – Stable weight value

Description

Use `s` to send a stable weight value, along with the display unit, from the balance to the connected communication partner via the interface.

Syntax

Command

<code>s</code>	Send the current stable net weight value.
----------------	---

Responses

<code>S_S_<WeightValue>_<Unit></code>	Current stable weight value in unit actually set under display unit.
<code>S_I</code>	Command understood but currently not executable (balance is currently executing another command, e.g., taring, or timeout as stability was not reached).
<code>S_+</code>	Balance in overload range.
<code>S_-</code>	Balance in underload range.

Parameters

Name	Type	Values	Meaning
<code><WeightValue></code>	Float		Weight value
<code><Unit></code>	String		Currently set display unit

Comments

- The duration of the timeout depends on the balance type.
- The weight value is formatted as a right aligned string with 10 characters including the decimal point. For details, please refer to Format of responses with weight value.
- To send the stable weight value in actually displayed unit, see [SU ▶ Page 122].

Example

↓	<code>s</code>	Send a stable weight value.
↑	<code>S_S_100.00_g</code>	The current, stable ("S") weight value is 100.00 g.

SI – Weight value immediately

Description

Use `SI` to immediately send the current weight value, along with the display unit, from the balance to the connected communication partner via the interface.

Syntax

Command

<code>SI</code>	Send the current net weight value, irrespective of balance stability.
-----------------	---

Responses

<code>S_S_<WeightValue>_<Unit></code>	Stable weight value in unit actually set under display unit.
<code>S_D_<WeightValue>_<Unit></code>	Non-stable (dynamic) weight value in unit actually set under display unit.
<code>S_I</code>	Command understood but currently not executable (balance is currently executing another command, e.g., taring).
<code>S_+</code>	Balance in overload range.
<code>S_-</code>	Balance in underload range.

Parameters

Name	Type	Values	Meaning
<code><WeightValue></code>	Float		Weight value
<code><Unit></code>	String		Currently set display unit

- The balance response to the command `SI` with the last built-in weight value (stable or dynamic) before receipt of the command `SI`.
- To send weight value immediately in actually displayed unit, see [SIU ▶ Page 97].
- The weight value is formatted as a right aligned string with 10 characters including the decimal point. For details, please refer to Format of responses with weight value.

Example

↓	<code>SI</code>	Send current weight value.
↑	<code>S_D_129.07_g</code>	The weight value is unstable (dynamic, "D") and is currently 129.07 g.

SIR – Weight value immediately and repeat

Description

Use `SIR` to immediately send the current weight value, along with the display unit, from the balance to the connected communication partner via the interface, but this time on a continuous basis.

Syntax

Command

<code>SIR</code>	Send the net weight values repeatedly, irrespective of balance stability.
------------------	---

Responses

<code>S_S_<WeightValue>_<Unit></code>	Stable weight value in unit actually set under display unit.
<code>S_D_<WeightValue>_<Unit></code>	Non-stable (dynamic) weight value in unit actually set under display unit.
<code>S_I</code>	Command understood but currently not executable (balance is currently executing another command, e.g., taring).
<code>S_+</code>	Balance in overload range.
<code>S_-</code>	Balance in underload range.

Parameters

Name	Type	Values	Meaning
<code><WeightValue></code>	Float		Weight value
<code><Unit></code>	String		Currently set display unit

- The number of weight values per second can be configured using [UPD ▶ Page 134].
- `SIR` is overwritten by the commands [S ▶ Page 93], [SI ▶ Page 94], [SR ▶ Page 117], [@ ▶ Page 14] and hardware break and hence cancelled.
- To send weight value in actually displayed unit, see [SIRU ▶ Page 96].
- This command is cancelled by the [@ ▶ Page 14], [S ▶ Page 93], [SI ▶ Page 94], [SIRU ▶ Page 96], [SIU ▶ Page 97], [SNR ▶ Page 113], [SNRU ▶ Page 115], [SR ▶ Page 117] and [SRU ▶ Page 119] commands.

Example

↓	<code>SIR</code>	Send current weight values at intervals.
↑	<code>S_D_129.07_g</code>	The balance sends stable ("S") or unstable ("D") weight values at intervals.
↑	<code>S_D_129.08_g</code>	
↑	<code>S_S_129.09_g</code>	
↑	<code>S_S_129.09_g</code>	
↑	<code>S_D_114.87_g</code>	
↑	<code>S_...</code>	

See also

[UPD – Update rate of SIR and SIRU output on the host interface ▶ Page 134](#)

SIRU – Weight value in display unit immediately and repeat

Description

Request current weight value in display unit independent of the stability and repeat sending responses until the command is stopped.

Syntax

Command

SIRU	Requests the current weight value and repeat.
------	---

Responses

S_S_<WeightValue>_<Unit>	Stable weight value in unit actually set under display unit.
S_D_<WeightValue>_<Unit>	Non-stable (dynamic) weight value in unit actually set under display unit.
S_I	Command understood but currently not executable (balance is currently executing another command, e.g., taring).
S_+	Balance in overload range.
S_-	Balance in underload range.

Parameters

Name	Type	Values	Meaning
<WeightValue>	Float		Weight value
<Unit>	String		Currently set display unit

Comments

- As the [SIR ▶ Page 95] command, but with currently displayed unit.
- The number of weight values per second can be configured using [UPD ▶ Page 134].
- This command is cancelled by the [@ ▶ Page 14], [S ▶ Page 93], [SI ▶ Page 94], [SIRU ▶ Page 96], [SIU ▶ Page 97], [SNR ▶ Page 113], [SNRU ▶ Page 115], [SR ▶ Page 117] and [SRU ▶ Page 119] commands.

Example

↓	SIRU	Query of the current weight value with currently displayed unit.
↑	S_D_12.34_lb	Non-stable (dynamic) weight value of 12.34 lb.
↑	S_D_12.44_lb	Non-stable (dynamic) weight value of 12.44 lb.
↑	S_D_12.43_lb	Non-stable (dynamic) weight value of 12.43 lb.

See also

- 🔗 SIR – Weight value immediately and repeat ▶ Page 95
- 🔗 UPD – Update rate of SIR and SIRU output on the host interface ▶ Page 134

SIU – Weight value in display unit immediately

Description

Request current weight value in display unit independent of the stability.

Syntax

Command

SIU	Request the current weight value in display unit.
-----	---

Responses

S_S_<WeightValue>_<Unit>	Stable weight value in unit actually set under display unit.
S_D_<WeightValue>_<Unit>	Non-stable (dynamic) weight value in unit actually set under display unit.
S_I	Command understood but currently not executable (balance is currently executing another command, e.g., taring).
S_+	Balance in overload range.
S_-	Balance in underload range.

Parameters

Name	Type	Values	Meaning
<WeightValue>	Float		Weight value
<Unit>	String		Currently set display unit

Comments

- As the [SI ▶ Page 94] command, but with currently displayed unit.

Example

↓	SIU	Requests the current weight value in display unit independent of the stability.
↑	S_D_12.34_lb	Non-stable (dynamic) weight value is 12.34 lb.

SIUM – Weight value in display unit and MinWeigh information immediately

Description

Use `SIUM` to immediately send the current weight value, along with the displayed unit and MinWeigh information, from the balance to the connected communication partner via the interface.

Syntax

Command

SIUM	Send the current net weight value with currently displayed unit and MinWeigh Information, irrespective of balance stability.
------	--

Responses

S_<Status>_<WeightValue>_<Unit>	Weight value in currently displayed unit.
S_I	Command understood but currently not executable (balance is currently executing another command, e.g. taring).
S_L	Command understood but not executable (incorrect parameter).
S_+	Balance in overload range.
S_-	Balance in underload range.

Parameters

Name	Type	Values	Meaning
<Status>	Char	S	Stable, net >= MinWeigh limit
		D	Dynamic, net >= MW limit
		M	Stable, net < MinWeigh limit
		N	Dynamic, net < MW limit
<WeightValue>	Float		Weight value
<Unit>	String		Currently displayed unit

Comments

- As the [SI ▶ Page 94] command, but with currently displayed unit and MinWeigh information.
- If the MinWeigh function is switched off, or is not available on the balance, it corresponds to the command [SIU ▶ Page 97].

Examples

↓	SIUM	Query of the current weight value with currently displayed unit.
↑	S_D_123.34_mg	Dynamic net weight displayed, greater than MinWeigh limit.
↓	SIUM	Query of the current weight value with currently displayed unit.
↑	S_M_123.34_mg	Stable net weight displayed, less than MinWeigh limit.
↓	SIUM	Query of the current weight value with currently displayed unit.
↑	S_N_123.34_mg	Dynamic net weight displayed, less than MinWeigh limit.

SIX1 – Current gross, net, tare values

Description

This command is intended to provide complete weighing information for a variety of applications. To provide complete weight information to the terminal or host software, several status flags are provided beside gross, net and tare value.

Syntax

Command

SIX1	Query the weighing information.
------	---------------------------------

Responses

SIX1_A_<Sts>_<MinW>_<CoZ>_<Rep>_<Calc>_<PosE>_<StepE>_<MarkE>_<Range>_<TM>_<G>_<N>_<T>_<Unit>	Current weighing information.
SIX1_I	The request could not be served because the state of the device did not allow it.

Examples

↓	SIX1	Query the current information for multi interval (see OIML R76-1 2006), device class II and gross is calculated ($G = N + T$). 1. Range 0 g to 3510 g, $e = 10d = 0.1$ g, ($e =$ approved, $d =$ display). 2. Range 3510 g to 7020 g, $e = d = 0.1$ g. 3. Range 7020 g to 35100 g, $e = d = 1$ g.
↑	SIX1_S_0_N_N_C_2_1_0_1_M_1496.33_621.67_874.66_g	Reads the parameters from the device ($G = 1496.324$ g, $N = 621.665$ g, $T = 874.659$ g). This example shows an stable weight with a calculated gross value. The tare is measured. The displayed gross value, which is the exact sum of the rounded net and rounded tare, does not always fulfill the rounding rules. This behavior is indicated by the "C" in the flags.
↑	SIX1_D_0_N_R_C_2_1_0_2_P_8496.36_6621.7_1874.66_g	Reads the parameters from the device ($G = 8496.324$ g, $N = 6621.665$ g, $T = 1874.659$ g). This example shows an unstable weight with a calculated gross value. Differently to the previous example, this update was sent already over the interface. This time the tare is preset and the net weight is in range 2. This explains the missing second decimal place in net value. All the same, the gross value has 2 decimal places to be able to display the exact addition of the net and tare values. It can be shown again that the calculated gross value does not need to fulfill any rounding rules regarding the exact gross value.
↑	SIX1_D_0_N_N_C_3_1_0_3_M_12496.66_10622_1874.66_g	Reads the parameters from the device ($G = 12496.324$ g, $N = 10621.665$ g, $T = 1874.659$ g). Now the net weight is in range 3. Now no decimal place is present at the net value. As above, the calculated gross value does not need to fulfill any rounding rules.

↑	<pre>SIX1_D_0_Z_N_C_2_1_0_1_N_0.00 0.00_0.00_g</pre>	<p>Reads the parameters from the device (G = 0.0024 g, N = 0.0024 g, T = 0.0000 g).</p> <p>This example shows the "center of zero" feature indicated by the "Z" in the command. It shows as well that the "center of zero" does not rely on stable values.</p>
↑	<pre>SIX1_S_0_N_N_C_2_1_0_1_M_1234.27 -888.97_2123.24_g</pre>	<p>Reads the parameters from the device (G = 1234.264 g, N = -888.971 g, T = 2123.235 g).</p> <p>This example shows how negative values are handled and displayed.</p>

↓	SIX1	<p>Query the current information for multi range (see OIML R76-1 2006), device class III and gross is calculated ($G = N + T$).</p> <ol style="list-style-type: none"> 1. Range 0 g to 3000 g, $e = d = 1$ g, ($e =$ approved, $d =$ display). 2. Range 0 g to 6000 g, $e = d = 2$ g. 3. Range 0 g to 15100 g, $e = d = 5$ g.
↑	SIX1_S_0_N_N_C_1_1_0_1_M_736 533_203_g	<p>Reads the parameters from the device ($G = 735.38$ g, $N = 532.63$ g, $T = 202.75$ g).</p> <p>This example shows an stable weight with a calculated gross value. The tare is measured. The displayed gross value, which is the exact sum of the rounded net and rounded tare, does not always fulfill the rounding rules. This behavior is indicated by the "C" in the flags. Different to the examples above, these have no decimal places and the configuration is multi range.</p>
↑	SIX1_D_0_N_R_C_1_5_0_3_P_7500 5225_2275_g	<p>Reads the parameters from the device ($G = 7496.33$ g, $N = 5223.62$ g, $T = 2272.71$ g).</p> <p>This weight update was sent before (indicated by "R") and the device is in range 3. This implies that all values have now step 5. Even so, this example demonstrates that the calculated gross value does not always conform the rounding rule. This time the tare was preset.</p>
↑	SIX1_D_0_Z_N_C_1_1_0_1_N_0 0_0_g	<p>Reads the parameters from the device ($G = 0.24$ g, $N = 0.24$ g, $T = 0.00$ g).</p> <p>This example shows the "center of zero" feature indicated by the "Z" in the command. It shows as well that the "center of zero" does not rely on stable values.</p>
↑	SIX1_S_0_N_N_C_1_5_0_3_M_4040 -2405_6445_g	<p>Reads the parameters from the device ($G = 4042.53$ g, $N = -2402.71$ g, $T = 6445.24$ g).</p> <p>This example shows how negative values are handled and displayed.</p>
↑	SIX1_I	The request could not be served because the state of the device did not allow it.
↑	SIX1_+	The request could not be served because of overload.

See also

- 🔗 [M21 – Unit ▶ Page 75](#)
- 🔗 [I38 – Type label range definitions ▶ Page 50](#)
- 🔗 [T – Tare ▶ Page 125](#)
- 🔗 [TA – Tare weight value ▶ Page 126](#)

SIX3 – Current gross, net, tare, HighResNet, MaxResNet values

Description

This command is intended to provide complete weighing information for a variety of applications. To provide complete weight information to the terminal or host software, several status flags are provided beside gross, net, tare, high resolution net and maximum resolution net value. The unit of this command is the host unit.

Syntax

Command

SIX3	Query the weighing information.
------	---------------------------------

Responses

SIX3_<Sts>_<MinW>_<CoZ>_<Rep>_<Calc>_<PosE>_<StepE>_<MarkE>_<Range>_<TM>_<G>_<N>_<T>_<HrSts>_<HR>_<MR>_<Unit>	Current weighing information.
SIX3_I	The request could not be served because the state of the device did not allow it.

Parameters

Name	Type	Values	Meaning
<Sts>	Char		Status of the weighing, linked to the net value
		S	Stable weight
		D	Dynamic weight (unstable, not accurate)
		+	Overload
		-	Underload
<MinW>	Integer	I	Invalid value
		0	MinWeigh status
		1	MinWeigh function is inactive
		2	Below MinWeigh limit. Relative accuracy is bad
		2	Above MinWeigh limit. Minimum relative accuracy is guaranteed
<CoZ>	Char		Center of zero status
		Z	+/- ¼ e around gross zero
		N	Outside the limits of +/- ¼ e around gross zero
<Rep>	Char		Repeating indicator
		R	Repeated value (was already sent once or more times)
		N	New weight update (new computed weight value)
<Calc>	Char		Calculation method indicator
		R	Net, tare and gross values are rounded separately
		C	Gross is calculated based on rounded net and rounded tare

Name	Type	Values	Meaning
<PosE>	Integer		Position of the approved digit e relative to base resolution (smallest digit d). Blanked digits (at the end) are counted. This parameter can be used on terminals to set the approval brackets at the correct position
		0	Not approved
		1	Approved, last digit is approved (no brackets)
		2	Approved, second last digit is approved
		3	Approved, third last digit is approved
		4	approved, fourth last digit is approved
<StepE>	Integer		Step of the approved digit
		0	Not approved
		1	Step of e is 1
		2	Step of e is 2
		5	Step of e is 5
<MarkE>	Integer		This flag indicates whether the weight value has to be marked as "not approved". A possible indication could be an asterisk
		0	No special indication needed
		1	Special indication (e.g. asterisk) has to be displayed
<Range>	Integer	1 ... n	Range/interval number of the net value. Numbering according OIML/NIST range numbering scheme (n is product dependent, maximum 9)
		1	Single range
		1, 2, ..., n	Multi range: range is linked to gross value
		1, 2, ..., n	Multi interval: range is linked to net value
<TM>	Char		Tare mode (no tare, manual tare, measured tare)
		N	No tare
		M	Measured tare
		P	Preset tare
<G>	String		Gross value
<N>	String		Net value rounded for actual range step
<T>	String		Tare value rounded for actual range step
<HrSts>	Char		Status of the high resolution net weight
		S	Stable weight (linked to net value)
		D	Dynamic weight (unstable, not accurate)
<HR>	String		High resolution net value
<MR>	String		Maximum resolution net value
<Unit>	String		The unit used for this command is the definition host unit The unit can be selected by using the [M21 ▶ Page 75] command.

Examples

↓	SIX3	<p>Query the current information for multi interval (see OIML R76-1 2006), device class II and gross is calculated ($G = N + T$).</p> <ol style="list-style-type: none"> 1. Range 0 g to 3510 g, $e = 10d = 0.1$ g, ($e =$ approved, $d =$ display). 2. Range 3510 g to 7020 g, $e = d = 0.1$ g. 3. Range 7020 g to 35100 g, $e = d = 1$ g.
↑	<p>SIX3_S_0_N_N_C_2_1_0_1_M_1496.33_621.67_874.66_g</p>	<p>Reads the parameters from the device ($G = 1496.324$ g, $N = 621.665$ g, $T = 874.659$ g).</p> <p>This example shows an stable weight with a calculated gross value. The tare is measured. The displayed gross value, which is the exact sum of the rounded net and rounded tare, does not always fulfill the rounding rules. This behavior is indicated by the "C" in the flags.</p>
↑	<p>SIX3_D_0_N_R_C_2_1_0_2_P_8496.36_6621.7_1874.66_g</p>	<p>Reads the parameters from the device ($G = 8496.324$ g, $N = 6621.665$ g, $T = 1874.659$ g).</p> <p>This example shows an unstable weight with a calculated gross value. Differently to the previous example, this update was sent already over the interface. This time the tare is preset and the net weight is in range 2. This explains the missing second decimal place in net value. All the same, the gross value has 2 decimal places to be able to display the exact addition of the net and tare values. It can be shown again that the calculated gross value does not need to fulfill any rounding rules regarding the exact gross value.</p>
↑	<p>SIX3_D_0_N_N_C_3_1_0_3_M_12496.66_10622_1874.66_g</p>	<p>Reads the parameters from the device ($G = 12496.324$ g, $N = 10621.665$ g, $T = 1874.659$ g).</p> <p>Now the net weight is in range 3. Now no decimal place is present at the net value. As above, the calculated gross value does not need to fulfill any rounding rules.</p>
↑	<p>SIX3_D_0_Z_N_C_2_1_0_1_N_0.00_0.00_0.00_g</p>	<p>Reads the parameters from the device ($G = 0.0024$ g, $N = 0.0024$ g, $T = 0.0000$ g).</p> <p>This example shows the "center of zero" feature indicated by the "Z" in the command. It shows as well that the "center of zero" does not rely on stable values.</p>
↑	<p>SIX3_S_0_N_N_C_2_1_0_1_M_1234.27_-888.97_2123.24_g</p>	<p>Reads the parameters from the device ($G = 1234.264$ g, $N = -888.971$ g, $T = 2123.235$ g).</p> <p>This example shows how negative values are handled and displayed.</p>

↓	SIX3	<p>Query the current information for multi range (see OIML R76-1 2006), device class III and gross is calculated ($G = N + T$).</p> <ol style="list-style-type: none"> 1. Range 0 g to 3000 g, $e = d = 1$ g, ($e =$ approved, $d =$ display). 2. Range 0 g to 6000 g, $e = d = 2$ g. 3. Range 0 g to 15100 g, $e = d = 5$ g.
↑	SIX3_S_0_N_N_C_1_1_0_1_M_736 533_203_g	<p>Reads the parameters from the device ($G = 735.38$ g, $N = 532.63$ g, $T = 202.75$ g).</p> <p>This example shows an stable weight with a calculated gross value. The tare is measured. The displayed gross value, which is the exact sum of the rounded net and rounded tare, does not always fulfill the rounding rules. This behavior is indicated by the "C" in the flags. Different to the examples above, these have no decimal places and the configuration is multi range.</p>
↑	SIX3_D_0_N_R_C_1_5_0_3_P_7500 5225_2275_g	<p>Reads the parameters from the device ($G = 7496.33$ g, $N = 5223.62$ g, $T = 2272.71$ g).</p> <p>This weight update was sent before (indicated by "R") and the device is in range 3. This implies that all values have now step 5. Even so, this example demonstrates that the calculated gross value does not always conform the rounding rule. This time the tare was preset.</p>
↑	SIX3_D_0_Z_N_C_1_1_0_1_N_0 0_0_g	<p>Reads the parameters from the device ($G = 0.24$ g, $N = 0.24$ g, $T = 0.00$ g).</p> <p>This example shows the "center of zero" feature indicated by the "Z" in the command. It shows as well that the "center of zero" does not rely on stable values.</p>
↑	SIX3_S_0_N_N_C_1_5_0_3_M_4040 -2405_6445_g	<p>Reads the parameters from the device ($G = 4042.53$ g, $N = -2402.71$ g, $T = 6445.24$ g).</p> <p>This example shows how negative values are handled and displayed.</p>
↑	SIX3_I	The request could not be served because the state of the device did not allow it.
↑	SIX3_+	The request could not be served because of overload.

See also

- 🔗 [M21 – Unit ▶ Page 75](#)
- 🔗 [I38 – Type label range definitions ▶ Page 50](#)
- 🔗 [T – Tare ▶ Page 125](#)
- 🔗 [TA – Tare weight value ▶ Page 126](#)

SM0 – Dynamic weighing: Cancel all SMx commands

Description

Use `SM0` to cancel any SMx commands that are in progress.

Syntax

Command

SM0	Cancel all SMx commands except [SM4 ▶ Page 112].
-----	--

Responses

SM0_A	Command understood and executed successfully.
SM0_I	Command understood but currently not executable (balance is currently executing another command or dynamic weighing application is not active or parameter is incorrect).

Comments

- This command can only be used with the application "Dynamic weighing". For details on available applications and how to activate them, see [M26 ▶ Page 80].
- Can only be executed if no weight is being applied respectively the "Dynamic weighing" window has disappeared.

Example

↓	SM0	Cancel all SMx commands except [SM4 ▶ Page 112].
↑	SM0_A_3	Any SMx commands are canceled.

See also

- [SM1 – Dynamic weighing: Start immediately and send the result ▶ Page 107](#)
- [SM2 – Dynamic weighing: Start after a minimum load is exceeded send result ▶ Page 108](#)
- [SM3 – Dynamic weighing: Start after a minimum load is exceeded, send result and repeat ▶ Page 110](#)
- [SM4 – Dynamic weighing: Time interval ▶ Page 112](#)

SM1 – Dynamic weighing: Start immediately and send the result

Description

Use `SM1` to start dynamic weighing immediately. The result is transferred via the interface once the weighing time has elapsed.

Syntax

Command

SM1	Start dynamic weighing immediately and transfer the result.
-----	---

First Responses

SM1_A	Dynamic weighing has been started, wait for second response. During the weighing operation, e.g. until the second response, no further commands can be executed.
SM1_I	Command understood but currently not executable (balance is currently executing another command or dynamic weighing application is not active or parameter is incorrect). No second response follows.

Further Responses

SM_*_<WeightValue>_<Unit>	Transfer of the result completed successfully. Weight value corresponds to the result of the measurement cycle. The unit corresponds to the current weight unit in the display.
SM_+	Abort, overload during the measurement cycle.
SM_-	Abort, underload during the measurement cycle.
SM_I	The dynamic weighing has been aborted.

Parameters

Name	Type	Values	Meaning
SM_*	String	S	Identification for dynamic weighing value
<WeightValue>	Float		Weight value in display unit
<Unit>	String		Weight unit

Comments

- This command can only be used with the application "Dynamic weighing". For details on available applications and how to activate them, see [M26 ▶ Page 80].
- Can only be executed if no weight is being applied respectively the "Dynamic weighing" window has disappeared.
- The balance does not perform stability or plausibility checks for the start.
- Prerequisite: A weight is already placed on the balance because weighing starts immediately after `SM1`.

Example

↓	SM1	Start a dynamic weighing immediately and transfer the result.
↑	SM1_A	Command understood, result follows.
↑	SM_*_#####23.76_g	Result of the dynamic weighing is 23.76 g.

SM2 – Dynamic weighing: Start after a minimum load is exceeded send result

Description

Use `SM2` to start dynamic weighing if the applied weight exceeds the specified minimum load. The result is transferred via the interface once the weighing time has elapsed.

Syntax

Command

SM2	Start a dynamic weighing automatically after the defined minimum load is exceeded and transfer the result (once).
-----	---

First Responses

SM2_A	Dynamic weighing has been started, wait for second response. During the weighing operation, e.g. until the second response, no further commands can be executed.
SM2_I	Command understood but currently not executable (balance is currently executing another command or dynamic weighing application is not active or parameter is incorrect). No second response follows.

Further Responses

SM_*_<WeightValue>_<Unit>	Transfer of the result completed successfully. Weight value corresponds to the result of the measurement cycle. The unit corresponds to the current weight unit in the display.
SM_+	Abort, overload during the measurement cycle.
SM_-	Abort, underload during the measurement cycle.
SM_I	The dynamic weighing has been aborted.

Parameters

Name	Type	Values	Meaning
SM_*	String	S	Identification for dynamic weighing value
<WeightValue>	Float		Weight value in display unit
<Unit>	String		Weight unit

Comments

- This command can only be used with the application "Dynamic weighing". For details on available applications and how to activate them, see [M26 ▶ Page 80].
- Can only be executed if no weight is being applied respectively the "Dynamic weighing" window has disappeared.
- The single start standby can be cancelled by the [SM0 ▶ Page 106] and [@ ▶ Page 14] commands before start of the weighing.
- The minimum load is defined as 5 g.

Example

↓	SM2	Start a dynamic weighing after the defined minimum load is exceeded and transfer the result.
↑	SM2_A	Command understood, result follows.
↑	SM_*_24.30_g	Result of the dynamic weighing is 24.30 g.

SM3 – Dynamic weighing: Start after a minimum load is exceeded, send result and repeat

Description

Use SM3 to start several dynamic weighing procedures in succession if the applied weights exceed the specified minimum load. The results are transferred via the interface once the weighing time has elapsed.

Syntax

Command

SM3	Start dynamic weighing automatically.
-----	---------------------------------------

First Responses

SM3_A	Dynamic weighing has been started, wait for second response. During the weighing operation, e.g. until the second response, no further commands can be executed.
SM3_I	Command understood but currently not executable (balance is currently executing another command or dynamic weighing application is not active or parameter is incorrect). No second response follows.

Further Responses

SM_*_<WeightValue>_<Unit>	Transfer of the result completed successfully. Weight value corresponds to the result of the measurement cycle. The unit corresponds to the current weight unit in the display. Further results follow when the start condition is fulfilled again.
SM_+	Abort, overload during the measurement cycle.
SM_-	Abort, underload during the measurement cycle.
SM_I	The dynamic weighing has been aborted.

Parameters

Name	Type	Values	Meaning
SM_*	String	S	Identification for dynamic weighing value
<WeightValue>	Float		Weight value in display unit
<Unit>	String		Weight unit

Comments

- This command can only be used with the application "Dynamic weighing". For details on available applications and how to activate them, see [M26 ▶ Page 80].
- Can only be executed if no weight is being applied respectively the "Dynamic weighing" window has disappeared.
- The recurring establishment of the start standby is cancelled by the [SM0 ▶ Page 106], [SM1 ▶ Page 107], [SM2 ▶ Page 108] and [@ ▶ Page 14] commands.
- The minimum load is defined as 5 g.

Example

↓	SM3	Start dynamic weighing when weight drops below and afterwards above the defined minimum load, transfer the result and repeat the process.
↑	SM3_A	Command understood, results follow.
↑	SM_*_25.83_g	Result of the 1 st dynamic weighing is 25.83 g.
↑	SM_*_22.91_g	Result of the 2 nd dynamic weighing is 22.91 g.
↑	SM_*_24.05_g	Result of the 3 rd dynamic weighing is 24.05 g.

SM4 – Dynamic weighing: Time interval

Description

Use SM4 to set the time interval for a dynamic weighing procedure, or query the current time setting.

Syntax

Commands

SM4	Query of the time interval for the dynamic weighing application.
SM4_<DynWeighTimeInterval>	Set the time interval for the dynamic weighing application.

Responses

SM4_A_<DynWeighTimeInterval>	Current time interval for the data acquisition of the dynamic weighing.
SM4_A	Command understood and executed successfully; time interval set.
SM4_I	Command understood but currently not executable (balance is currently executing another command).
SM4_L	Command understood but not executable (e.g. dynamic weighing application is not active or parameter is incorrect).

Parameter

Name	Type	Values	Meaning
<DynWeighTimeInterval>	Integer	0 ... 120	Time interval in seconds

Comments

- This command can only be used with the application "Dynamic weighing". For details on available applications and how to activate them, see [M26 ▶ Page 80].
- Can only be executed if no weight is being applied respectively the "Dynamic weighing" window has disappeared.

Example

↓	SM4_14	Set the time interval for the data acquisition of the dynamic weighing to 14 seconds.
↑	SM4_A	Current time interval is set to 14 seconds.

SNR – Send stable weight value and repeat on stable weight change

Description

Request the current stable weight value in display unit followed by stable weight values after predefined minimum weight changes until the command is stopped.

Syntax

Commands

SNR	Send the current stable weight value and repeat after each deflection (see comment).
SNR_<PresetValue>_<Unit>	Send the current stable weight value and repeat after each deflection greater or equal to the preset value (see comment).

Responses

S_S_<WeightValue>_<Unit> S_S_<WeightValue>_<Unit> ...	Current stable weight value (1 st value). Next stable weight value after preset deflection (2 nd value). ...
S_I	Command understood but currently not executable (balance is currently executing another command, e.g. taring, or timeout as stability was not reached).
S_L	Command understood but not executable (incorrect parameter).
S_+	Balance in overload range.
S_-	Balance in underload range.

Parameters

Name	Type	Values	Meaning
<PresetValue>	Float	1 digit ... capacity	Preset minimum deflection load
<Unit>	String		Currently set display unit

Comments

- The preset value is optional. If no value is defined, the deflection depends on balance readability as follows:

Readability	Min. deflection
0.001 mg	0.001 g
0.01 mg	0.01 g
0.1 mg	0.1 g
0.001 g	1 g
0.01 g	1 g
0.1 g	1 g
1 g	5 g

- In contrast to `SNR`, [`SR` ▶ Page 117] sends also dynamic weight values.
- This command is cancelled by the [`@` ▶ Page 14], [`S` ▶ Page 93], [`SI` ▶ Page 94], [`SIR` ▶ Page 95], [`SIU` ▶ Page 97], [`SIRU` ▶ Page 96], [`SNRU` ▶ Page 115], [`SR` ▶ Page 117] and [`SRU` ▶ Page 119] commands.

Example

↓	SNR_50_g	Send the current stable weight value and repeat after each deflection greater or equal to the preset value of 50 g.
↑	S_S_12.34_g	1 st weight value is 12.34 g.
↑	S_S_67.89_g	2 nd weight value is 67.89 g.

SNRU – Send stable weight value with currently displayed unit and repeat on stable weight change

Description

Request the current stable weight value in display unit followed by stable weight values after predefined minimum weight changes until the command is stopped.

Syntax

Commands

SNRU	Send the current stable weight value with the currently displayed unit and repeat after each deflection (see comment).
SNRU_<PresetValue>_<Unit>	Send the current stable weight value with the currently displayed unit and repeat after each deflection greater or equal to the preset value (see comment).

Responses

S_S_<WeightValue>_<Unit> S_S_<WeightValue>_<Unit> ...	Current stable weight value (1 st value). Next stable weight value after preset deflection (2 nd value). ...
S_I	Command understood but currently not executable (balance is currently executing another command, e.g. taring, or timeout as stability was not reached).
S_L	Command understood but not executable (incorrect parameter).
S_+	Balance in overload range.
S_-	Balance in underload range.

Parameters

Name	Type	Values	Meaning
<PresetValue>	Float	1 digit ... capacity	Preset minimum deflection load
<Unit>	String		Currently set display unit

Comments

- The preset value is optional. If no value is defined, the deflection depends on balance readability as follows:

Readability	Min. deflection
0.001 mg	0.001 g
0.01 mg	0.01 g
0.1 mg	0.1 g
0.001 g	1 g
0.01 g	1 g
0.1 g	1 g
1 g	5 g

- In contrast to `SNR`, [SR ▶ Page 117] sends also dynamic weight values.
- This command is cancelled by the [@ ▶ Page 14], [S ▶ Page 93], [SI ▶ Page 94], [SIR ▶ Page 95], [SIU ▶ Page 97], [SIRU ▶ Page 96], [SNRU ▶ Page 115], [SR ▶ Page 117] and [SRU ▶ Page 119] commands.

Example

↓	SNRU_50_g	Send the current stable weight value with the currently displayed unit and repeat after each deflection greater or equal to the preset value of 50 g.
↑	S_S_12.34_g	1 st weight value is 12.34 g.
↑	S_S_67.89_g	2 nd weight value is 67.89 g.

See also

[🔗](#) SNR – Send stable weight value and repeat on stable weight change ▶ Page 113

SR – Send stable weight value and repeat on any weight change

Description

Request the current stable weight value in display unit followed by weight values after predefined minimum weight changes until the command is stopped.

Syntax

Commands

SR	Send the current stable weight value and then continuously after every weight change If no preset value is entered, the weight change must be at least 12.5% of the last stable weight value, minimum = 30 digit.
SR_<PresetValue>_<Unit>	Send the current stable weight value and then continuously after every weight change greater or equal to the preset value a non-stable (dynamic) value followed by the next stable value, range = 1 digit to maximal capacity.

Responses

S_S_<WeightValue>_<Unit>	Current, stable weight value in unit actually set as display unit, 1 st weight change.
S_D_<WeightValue>_<Unit>	Dynamic weight value in unit actually set as display unit.
S_S_<WeightValue>_<Unit>	Next stable weight value in unit actually set as display unit.
S_I	Command understood but currently not executable (balance is currently executing another command, e.g. zero setting, or timeout as stability was not reached).
S_L	Command understood but not executable (incorrect parameter).
S_+	Balance in overload range.
S_-	Balance in underload range.

Parameters

Name	Type	Values	Meaning
<WeightValue>	Float		Weight value
<Unit>	String		Unit, only available units permitted

Comments

- This command is cancelled by the [@ ▶ Page 14], [S ▶ Page 93], [SI ▶ Page 94], [SIR ▶ Page 95], [SIU ▶ Page 97], [SIRU ▶ Page 96], [SNRU ▶ Page 115], [SR ▶ Page 117] and [SRU ▶ Page 119] commands.
- In contrast to SR, [SNR ▶ Page 113] only sends stable weight values.
- If, following a non-stable (dynamic) weight value, stability has not been reached within the timeout interval, the response S_I is sent and then a non-stable weight value. Timeout then starts again from the beginning.
- The preset value can be entered in any by the balance accepted unit.

Example

↓	SR_10.00_g	Send the current stable weight value followed by every load change of 10 g.
↑	S_S_____100.00_g	Balance stable.
↑	S_D_____115.23_g	100.00 g loaded.
↑	S_S_____200.00_g	Balance again stable.

See also

[🔗](#) SNR – Send stable weight value and repeat on stable weight change ▶ Page 113

SRU – Send stable weight value with currently displayed unit and repeat on any weight change

Description

Request the current weight values in display unit and repeat sending responses after a predefined minimum weight change until the command is stopped.

Syntax

Commands

SRU	Send the current stable weight value with the currently displayed unit and then continuously after every weight change. If no preset value is entered, the weight change must be at least 12.5% of the last stable weight value, minimum = 30 digit.
SRU_<WeightValue>_<Unit>	Send the current stable weight value with the currently displayed unit and then continuously after every weight change greater or equal to the preset value a non-stable (dynamic) value followed by the next stable value, range = 1 digit to maximal capacity.

Responses

S_S_<WeightValue>_<Unit>	Current, stable weight value with the currently displayed unit until 1 st weight change.
S_D_<WeightValue>_<Unit>	Non-stable (dynamic) weight value with the currently displayed unit.
S_I	Command understood but currently not executable (balance is currently executing another command, e.g. taring).
S_+	Balance in overload range.
S_-	Balance in underload range.

Parameters

Name	Type	Values	Meaning
<WeightValue>	Float		Weight value
<Unit>	String		Unit, only available units permitted

Comments


- As the [SR ▶ Page 117] command, but with currently displayed unit.
- This command is cancelled by the [@ ▶ Page 14], [S ▶ Page 93], [SI ▶ Page 94], [SIR ▶ Page 95], [SIU ▶ Page 97], [SIRU ▶ Page 96], [SNRU ▶ Page 115], [SR ▶ Page 117] and [SRU ▶ Page 119] commands.
- In contrast to [SR ▶ Page 117], [SNRU ▶ Page 115] only sends stable weight values.
- If, following a non-stable (dynamic) weight value, stability has not been reached within the timeout interval, the response S_I is sent and then a non-stable weight value. Timeout then starts again from the beginning.
- The preset value can be entered in any by the balance accepted unit.

Example

↓	SRU	Send the current stable weight value followed by every default load change with current display unit.
↑	S_S_12.34_lb	1 st weight value is stable and 12.34 lb.
↑	S_D_13.88_lb	2 nd weight value is non-stable and 13.88 lb.
↑	S_S_15.01_lb	3 rd weight value is stable and 15.01 lb.


ST – Stable weight value on pressing (Transfer) key

Description



Use `ST` to send the current stable weight value when the transfer key  is pressed. The value is sent, along with the currently displayed unit, from the balance to the connected communication partner via the interface.

Syntax

Commands

<code>ST</code>	Query the current status transfer function.
<code>ST_1</code>	Sent the current stable net weight value with display unit each time when the transfer key  is pressed.
<code>ST_0</code>	Stop sending weight value when print key is pressed.

Responses

<code>ST_A_0</code>	Function inactive, no weight value is sent when the transfer key  is pressed.
<code>ST_A_1</code>	Function active, weight value is sent each time when the transfer key  is pressed.
<code>ST_A</code>	Command understood and executed successfully.
<code>ST_I</code>	Command understood but currently not executable (balance is currently executing another command).
<code>ST_L</code>	Command understood but not executable (incorrect parameter).


Parameter

Name	Type	Values	Meaning
<code><Status></code>	Boolean		Behavior of the transfer function
		0	Inactive
		1	Active

Comments

- `ST_0` is the factory setting (default value).
- `ST` function is not active after switching on and after reset command.

Example

↓	<code>ST_1</code>	Activate <code>ST</code> function.
↑	<code>ST_A</code>	Command executed.
↑	<code>S_S_____123.456_g</code>	When transfer key  pressed: current net weight is 123.456 g.

SU – Stable weight value in display unit

Description

Use `SU` to query the stable weight value in display unit.

Syntax

Command

<code>SU</code>	Query the stable weight value with the currently displayed unit.
-----------------	--

Responses

<code>S_S_<WeightValue>_<Unit></code>	Current stable weight value with the currently displayed unit.
<code>S_I</code>	Command understood but currently not executable (balance is currently executing another command, e.g. taring, or timeout as stability was not reached).
<code>S_+</code>	Balance in overload range.
<code>S_-</code>	Balance in underload range.

Comments

- As the [S ▶ Page 93] command, but with currently displayed unit.

Example

↓	<code>SU</code>	Query the stable weight value with the currently displayed unit.
↑	<code>S_S_12.34_lb</code>	The current, stable weight value is 12.34 lb.

SUM – Stable weight value in display unit and MinWeigh information

Description

Use `SUM` to send the current stable weight value, along with the currently displayed unit and the MinWeigh information, from the balance to the connected communication partner via the interface.

Syntax

Command

<code>SUM</code>	Send the current stable net weight value with currently displayed unit and MinWeigh Information.
------------------	--

Responses

<code>SUM_<Status>_<WeightValue>_<Unit></code>	Weight value in currently displayed unit.
<code>S_I</code>	Command understood but currently not executable (balance is currently executing another command, e.g. taring).
<code>S_L</code>	Command understood but not executable (incorrect parameter).
<code>S_+</code>	Balance in overload range.
<code>S_-</code>	Balance in underload range.

Parameters

Name	Type	Values	Meaning
<code><Status></code>	Char	S M	Stable, \geq MinWeigh limit Stable, $<$ MinWeigh limit
<code><WeightValue></code>	Float		Weight value
<code><Unit></code>	String		Weight unit

Comments

- As the [S ▶ Page 93] command, but with currently displayed unit and MinWeigh information.
- If a weight other than the net weight is displayed, only the "S" index and the stable weight value displayed are output on the interface.
- If the MinWeigh function is switched off or not available on the balance, the corresponding command is [SU ▶ Page 122].

Examples

↓	<code>SUM</code>	Query of the current weight value with currently displayed unit.
↑	<code>S_M_123.34_mg</code>	Stable weight displayed, less than MinWeigh limit.
↓	<code>SUM</code>	Query of the current weight value with currently displayed unit.
↑	<code>S_S_123.34_mg</code>	Stable weight displayed, greater than MinWeigh limit.

SXIR – Send weighing data immediately and repeat

Description

Use SXIR to immediately send the current weighing data with the currently displayed unit to the connected communication partner via the interface and repeat sending responses until the command is stopped.

Syntax

Command

SXIR	Send current weighing data immediately with the currently displayed unit and repeat.
------	--

Responses

SX_S_x1_x2_x3_x4_x5_x6	Current stable gross, net and tare weights x1 = gross (G_.....) x2 = unit of gross weight x3 = net (N_.....) x4 = unit of net weight x5 = tare (T_.....) x6 = unit of tare weight
SX_D_x1_x2_x3_x4_x5_x6	Current unstable (dynamic) gross, net and tare weights x1 ... x6: see above
SX_I	Command understood but not executable
SX_+	Balance in overload range
SX_-	Balance in underload range

Example

↓	SXIR	Send weighing data immediately and repeat.
↑	SXVD_G_2.00030_kg_N_1.99970_kg_ T_0.00060_kg SXVS_G_2.00033_kg_N_1.99972_kg_ T_0.00061_kg ...	Dynamic weight values Stable weight values

Comments

- This command is overwritten by all send commands and hardware breaks and, thus, canceled.
- The number of weight values per second depends on the balance type.

See also

[@](#) – Abort ▶ Page 14

[S](#) – Stable weight value ▶ Page 93

[SI](#) – Weight value immediately ▶ Page 94

[SR](#) – Send stable weight value and repeat on any weight change ▶ Page 117

T – Tare

Description

Use **T** to tare the balance. The next stable weight value will be saved in the tare memory.

Syntax

Command

T	Tare, i.e. store the next stable weight value as a new tare weight value.
---	---

Responses

T_S_<TareValue>_<Unit>	Taring successfully performed. The tare weight value returned corresponds to the weight change on the balance in the unit actually set under display unit since the last zero setting.
T_I	Command understood but currently not executable (balance is currently executing another command, e.g., zero setting, or timeout as stability was not reached).
T_L	Command understood but not executable (incorrect parameter).
T_+	Upper limit of taring range exceeded.
T_-	Lower limit of taring range exceeded.

Parameters

Name	Type	Values	Meaning
<TareValue>	Float		Weight value in host unit
<Unit>	String		Weight unit

Comments

- The tare memory is overwritten by the new tare weight value.
- The duration of the timeout depends on the balance type.
- Clearing tare memory, see [TAC ▶ Page 127].

Example

↓	T	Tare.
↑	T_S_100.00_g	The balance is tared and has a value of 100.00 g in the tare memory.

See also

- 🔗 TA – Tare weight value ▶ Page 126
- 🔗 TAC – Clear tare weight value ▶ Page 127

TA – Tare weight value

Description

Use **TA** to query the current tare value or preset a known tare value.

Syntax

Commands

TA	Query of the current tare weight value.
TA_<TarePresetValue>_<Unit>	Preset of a tare value.

Responses

TA_A_<TareWeightValue>_<Unit>	Query current tare weight value in tare memory, in unit actually set under display unit.
TA_I	Command understood but currently not executable (balance is currently executing another command, e.g., zero setting, or timeout as stability was not reached).
TA_L	Command understood but not executable (incorrect parameter).

Parameters

Name	Type	Values	Meaning
<TareWeightValue>	Float		Tare weight value in host unit
<Unit>	String		Weight unit

Comments

- The tare memory will be overwritten by the preset tare weight value.
- The inputted tare value will be automatically rounded by the balance to the current readability. This value is shown in the response.
- The taring range is specified to the balance type.

Example

↓	TA_100.00_g	Preset a tare weight of 100 g.
↑	TA_A_100.00_g	The balance has a value of 100.00 g in the tare memory.

See also

- [T – Tare](#) ▶ Page 125
- [TAC – Clear tare weight value](#) ▶ Page 127

TAC – Clear tare weight value

Description

Use TAC to clear the tare memory.

Syntax

Command

TAC	Clear tare value.
-----	-------------------

Responses

TAC_A	Tare value cleared, 0 is in the tare memory.
TAC_I	Command understood but currently not executable (balance is currently executing another command, e.g. zero setting).
T_L	Command understood but not executable (incorrect parameter).

Example

↓	TAC	Clear tare value.
↑	TAC_A	Tare value cleared, 0 is in the tare memory.

See also

- [T – Tare ▶ Page 125](#)
- [TI – Tare immediately ▶ Page 128](#)
- [TA – Tare weight value ▶ Page 126](#)

TI – Tare immediately

Description

Use **TI** to tare the balance immediately and independently of balance stability.

Syntax

Command

TI	Tare immediately, i.e. store the current weight value, which can be stable or non stable (dynamic), as tare weight value.
----	---

Responses

TI_S_<WeightValue>_<Unit>	Taring performed, stable tare value. The new tare value corresponds to the weight change on the balance since the last zero setting.
TI_D_<WeightValue>_<Unit>	Taring performed, non-stable (dynamic) tare value.
TI_I	Command understood but currently not executable (balance is currently executing another command, e.g. zero setting).
TI_L	Command understood but not executable (e.g. approved version of the balance).
TI_+	Upper limit of taring range exceeded.
TI_-	Lower limit of taring range exceeded.

Parameters

Name	Type	Values	Meaning
<WeightValue>	Float		Tare weight value in host unit
<Unit>	String		Weight unit

Comments

- This command is not supported by approved balances.
- The tare memory will be overwritten by the new tare weight value.
- After a non-stable (dynamic) stored tare weight value, a stable weight value can be determined. However, the absolute value of the stable weight value determined in this manner is not accurate.
- The taring range is specific to the balance type.

Example

↓	TI	Tare immediately.
↑	TI_D_117.57_g	The tare memory holds a non-stable (dynamic) weight value.

See also

- [T – Tare ▶ Page 125](#)
- [TA – Tare weight value ▶ Page 126](#)
- [TAC – Clear tare weight value ▶ Page 127](#)

TIM – Time

Description

Set the system time of the balance or query the current time.

Syntax

Commands

TIM	Query of the current time of the balance.
TIM_<Hour>_<Minute>_<Second>	Set the time of the balance.

Responses

TIM_A_<Hour>_<Minute>_<Second>	Current time of the balance.
TIM_A	Command understood and executed successfully.
TIM_I	Command understood but currently not executable (balance is currently executing another command).
TIM_L	Command understood but not executable (incorrect parameter, e.g. 22_67_25) or no clock is built in.

Parameters

Name	Type	Values	Meaning
<Hour>	Integer	00 ... 23	Hours
<Minute>	Integer	00 ... 59	Minutes
<Second>	Integer	00 ... 59	Seconds

Comment

If NTP is active, the time set by the TIM command will be overwritten.

Example

↓	TIM	Query of the current time of the balance.
↑	TIM_A_09_56_11	The current time of the balance is 9 hours, 56 minutes and 11 seconds.

See also

[DAT – Date](#) ▶ Page 29

TST2 – Test with external weight

Description

Use TST2 to start the balance test function using external test weights.

Syntax

Command

TST2	Start test function with external weight.
------	---

First Responses

TST2_B	The test procedure has been started. Wait for next response, see Comment.
TST2_A_<"Deviation">	Test completed, current difference is mention.
TST2_I	Command understood but currently not executable (balance is currently executing another command). No second response follows.
TST2_L	Command understood but not executable (incorrect parameter). No second response follows.

Further Responses

TST2_<"TestWeight">_<"Unit">	Prompt to unload and load the balance.
TST2_A_<"TestWeight">_<"Unit">	Test procedure completed successfully. Weight value with unit corresponds to the deviation from the specified value displayed in the top line after the test.
TST2_I	The test procedure has been aborted as, e.g. stability was not attained or wrong weights were loaded.

Parameters

Name	Type	Values	Meaning
<"Deviation">	String		Current difference in definition unit
<"TestWeight">	String		Value of the test weight in definition unit
<"Unit">	String		Weight unit. Fixed to definition unit

Comments

- Commands sent to the balance during the test procedure are not processed and responded to in the appropriate manner until the test procedure is at an end.
- For additional information on testing the adjustment, see the Reference Manual of the balance.
- The value of the external weight is set in the menu under "Adjustments".

Example

↓	TST2	Start test with external weight.
↑	TST2_B	The test procedure has been started.
↑	TST2_"_0.00_g"	Prompt to unload the balance.
↑	TST2_"_200.00_g"	Prompt to load the test weight.
↑	TST2_"_0.00_g"	Prompt to unload the balance.
↑	TST2_A_"_0.01_g"	External test completed successfully.

See also

- [@ – Abort](#) ▶ Page 14
- [C – Cancel all commands](#) ▶ Page 23
- [M20 – Test weight](#) ▶ Page 74
- [M20 – Test weight](#) ▶ Page 74

TST3 – Test with built-in weight

Description

Use `TST3` to start the sensitivity test function using built-in test weight.

Syntax

Command

<code>TST3</code>	Start sensitivity test function with built-in test weight.
-------------------	--

Responses

<code>TST3_B</code>	The test procedure has been started. Wait for next response, see Comments.
<code>TST3_A_<"DeviationValue"></code>	Test procedure completed successfully. Weight value corresponds to the deviation from the specified value displayed after the test.
<code>TST3_I</code>	Command understood but currently not executable (balance is currently executing another command). No second response follows. The test procedure has been aborted as, e.g., stability was not attained or wrong weights were loaded.
<code>TST3_L</code>	Command understood but not executable (incorrect parameter). No second response follows.

Parameter

Name	Type	Values	Meaning
<code><"DeviationValue"></code>	String		Current difference (deviation value is output without unit)

Comments

- For additional information on testing the adjustment, see the Reference Manual of the balance.
- The unit is fixed to definition unit, no unit is output since the built-in weight is used.

Example

↓	<code>TST3</code>	Start sensitivity test with built-in weight.
↑	<code>TST3_B</code>	The test procedure has been started.
↑	<code>TST3_A_ "_____0.0002"</code>	Test with internal weight completed successfully. The difference to the specified value is 0.0002 (= 2 digits from a weigh module/balance with an increment of 0.1 mg).

See also

- [@ – Abort](#) ▶ Page 14
- [C – Cancel all commands](#) ▶ Page 23
- [C3 – Start adjustment with built-in weight](#) ▶ Page 27

TST4 – Repeatability test

Description

This command initializes the repeatability test with the built-in weight and gets the results of the repeatability test.

Syntax

Command

TST4_No	Start repeatability test with no cycles.
---------	--

Response

TST4_A_<"SDev">_<"Unit">_<MaxTemp>_<MinTemp>_<MeanTemp>_<Hour>_<Minute>_<Second>	Repeatability test completed successfully. Command understood but currently not executable (balance is currently executing another command).
TST4_I	The test procedure has been aborted as, e.g., stability was not attained or wrong weights were loaded.

Parameters

Name	Type	Values	Meaning
<No>	Integer	5 ... 100	Number of repeatability test times
<"SDev">	String	10 char	Standard deviation of tested weighing load and definition unit
<"Unit">	String		Unit of tested weighing load
<MaxTemp>	Float		Maximum temperature during test, in °C
<MinTemp>	Float		Minimum temperature during test, in °C
<MeanTemp>	Float		Average temperature during test, in °C
<Hour>	Integer	0 ... 23	Hours of the total time of repeatability test
<Minute>	Integer	0 ... 59	Minutes of the total time of repeatability test
<Second>	Integer	0 ... 59	Seconds of the total time of repeatability test

Comments

- For additional information on testing the adjustment, see the Reference Manual of the balance.

Example

↓	TST4_5	Executes repeatability test with testing number 5.
↑	TST4_B_0	Start repeatability test.
↑	TST4_B_1 ... TST4_B_5	Start of repeatability test cycles.
↑	TST4_A_"0.01_g" 25.3_23.4_24.5_00_01_23	Test successfully. The standard deviation is 0.001 g, maximum temperature is 25.3 °C; minimum temperature is 23.4 °C; average temperature is 24.5 °C. Whole test time is 1 minute and 23 seconds.

See also

[@](#) – Abort ▶ Page 14

[C](#) – Cancel all commands ▶ Page 23

UPD – Update rate of SIR and SIRU output on the host interface

Description

Use `UPD` to set the update rate of the host interface or query the current setting.

Syntax

Commands

<code>UPD</code>	Query of the update rate of the host interface.
<code>UPD_<CurrentUPD></code>	Set the update rate of the host interface.

Responses

<code>UPD_A_<CurrentUPD></code>	Current setting of the update rate of the host interface.
<code>UPD_A</code>	Command understood and executed successfully.
<code>UPD_I</code>	Command understood but currently not executable (balance is currently executing another command).
<code>UPD_L</code>	Command understood but not executable (incorrect parameter).

Parameter

Name	Type	Values	Meaning
<code><UpdateRate></code>	Float	0.1 ... 100 0	Update rate in values per second 0.1 ... 22.9

Comments

- The parameter setting will be saved and the only way to reset the default value will be via MT-SICS.
- The balance can not realize every arbitrary update rate. The specified update rate is therefore rounded to the next realizable update rate. Use `UPD` without parameter to query the actually configured update rate. The achievable update rate depends on the signal processing and baud rate used. Check the current update rate with the command query `UPD`. The required minimum baud rate is 220 times the actual update rate

Examples

↓	<code>UPD</code>	Query of the update rate of the host interface.
↑	<code>UPD_A_20.2</code>	The update rate of the interface is 20.2 values per second.
↓	<code>UPD_20</code>	Set the update rate of the host interface to 20 values per second.
↑	<code>UPD_A</code>	Command executed successfully.
↑	<code>UPD</code>	Query of the exact update rate of the host interface.
↑	<code>UPD_A_18.311</code>	The exact update rate is 18.311 values per second.

See also

- 🔗 [SIR – Weight value immediately and repeat ▶ Page 95](#)
- 🔗 [SIRU – Weight value in display unit immediately and repeat ▶ Page 96](#)

Z – Zero

Description

Use `z` to set a new zero; all weight values (including the tare weight) will be measured relative to this zero. After zeroing has taken place, the following values apply: tare weight = 0; net weight (= gross weight) = 0.

Syntax

Command

<code>z</code>	Zero the balance.
----------------	-------------------

Responses

<code>z_A</code>	Zero setting successfully performed. Gross, net and tare = 0.
<code>z_I</code>	Command understood but currently not executable (balance is currently executing another command, e.g. taring, or timeout as stability was not reached).
<code>z_+</code>	Upper limit of zero setting range exceeded.
<code>z_-</code>	Lower limit of zero setting range exceeded.

- The zero point determined during switching on is not influenced by this command, the measurement ranges remain unchanged.
- The duration of the timeout depends on the balance type.
- The tare memory is cleared after zero setting.

Example

↓	<code>z</code>	Zero.
↑	<code>z_A</code>	Zero setting performed.

See also

[ZI – Zero immediately](#) ▶ Page 136

ZI – Zero immediately

Description

Use `ZI` to set a new zero immediately, regardless of balance stability. All weight values (including the tare weight) will be measured relative to this zero. After zeroing has taken place, the following values apply: tare weight = 0; net weight (= gross weight) = 0.

Syntax

Command

<code>ZI</code>	Zero the balance immediately regardless the stability of balance.
-----------------	---

Responses

<code>ZI_D</code>	Re-zero performed under non-stable (dynamic) conditions.
<code>ZI_S</code>	Re-zero performed under stable conditions.
<code>ZI_I</code>	Command understood but currently not executable (balance is currently executing another command, e.g. taring).
<code>ZI_+</code>	Upper limit of zero setting range exceeded.
<code>ZI_-</code>	Lower limit of zero setting range exceeded.

- This command is not supported by approved balances.
- The zero point determined during switching on is not influenced by this command, the measurement ranges remain unchanged.
- The tare memory is cleared after zero setting.

Example

<code>_</code>	<code>ZI</code>	Zero immediately.
<code>_</code>	<code>ZI_D</code>	Re-zero performed under non-stable (dynamic) conditions.

See also

[Z – Zero](#) ▶ Page 135

4 What if...?

Tips from actual practice if the communication between the system (computer) and the balance is not working.

Establishing the communication

Switch the balance off / on.

The balance must now send identification string [I4 ▶ Page 37], e.g., `I4_A_ "0123456789"`.

If this is not the case, check the following points.

Connection

For RS232 communication, at least three connecting lines are needed:

- Data line from the balance (TxD signal).
- Data line to the balance (RxD signal).
- Signal ground line (GNDINT).

Make sure that all these connections are in order. Check the connector pin assignment of the connection cables.

Interface parameters

For the transmission to function properly, the settings of the following parameters must match at both the computer and the balance:

- Baud rate (send/receive rate)
- Number of data bits
- Parity bit

Check the settings at both devices.

Handshake

For control of the transmission, in part separate connection lines are used (CTS/DTR). If these lines are missing or wrongly connected, the computer or balance can not send or receive data.

Check whether the weigh module/balance is prevented from transmitting by handshake lines (CTS or DTR). Set the parameter "protocol" for the weigh module/balance and the peripheral device to "No Handshake" or "none". The handshake lines now have no influence on the communication.

Characters are not displayed correctly

In order to display ASCII characters >127 dec., ensure that 8-bit communication is taking place.

See also

[🔗 I4 – Serial number ▶ Page 37](#)

Index

A

Adjustment	
C0	24
C1	26
C3	27
I64	57
M19	73
M27	81

B

Balance ID	
I10	39
Balance information	
I0	32
I1	33
I10	39
I11	40
I14	41, 55
I2	35
I26	43
I3	36
I33	46
I4	37
I5	38
I51	52
I65	58
I66	59
I67	60
I68	61
Balance settings	
C	23
I27	44
M121	88
M21	75
Beep signal	
M12	72
Commands	11

C

Cancel	
@	14
DW	30
SMO	106
Check weighing	
M30	83

D

Data interface	
UPD	134
Display	
D	28
DW	30
E01	31
K	65
M08	70
M11	71
M12	72
M23	78
P121	89
PWR	91
Dynamic weighing	
SM0	106
SM1	107
SM2	108
SM3	110
SM4	112
Dynamic weighing application	
M26	80

F

Factor weighing	
M22	77

H

Network configuration	
M70	86

I

I72	63
ID balance	
I10	39

L

List of commands	11
I0	32

M

MinWeigh Application	
SIUM	98
SUM	123

N		SIUM	98
Network configuration		SIX1	99
M70	86	SIX3	102
Network configuration		SNR	113
I53	53	SNRU	115
M69	84	SR	117
P		SRU	119
Percent weighing application		ST	121
M26	80	SU	122
Piece counting application		SUM	123
M26	80	SXIR	124
PW	90	Weighing application	
R		A35	16
Restart		A36	19
R01	92	A37	21
S		Weighing filter setup	
Service		M01	67
I70	62	M02	68
Status		M03	69
DAT	29	M29	82
IO	32	Weighing to a nominal value	
PWR	91	A10	15
TIM	129	Z	
T		Zeroing	
Taring		Z	135
T	125	ZI	136
TA	126		
TAC	127		
TI	128		
Terminal			
see Display	28		
Test function			
M20	74		
TST2	130		
TST3	132		
TST4	133		
W			
Weighing			
S	93		
SI	94		
SIR	95		
SIRU	96		
SIU	97		

To protect your product's future:

METTLER TOLEDO Service assures the quality, measuring accuracy and preservation of value of this product for years to come.

Please request full details about our attractive terms of service.

► www.mt.com/service

www.mt.com/balances

For more information

Mettler-Toledo GmbH

Im Langacher 44
8606 Greifensee, Switzerland
www.mt.com/contact

Subject to technical changes.
© 12/2023 METTLER TOLEDO. All rights reserved.
30572179A en



30572179