


**METTLER**      **TOLEDO**

**Installation instructions**  
**Montageanleitung**  
**Notice de montage**

**Interface description**

**METTLER TOLEDO**  
**RS-232 interface**  
**for BD balances**  
**RS-232-Schnittstelle**  
**für BD-Waagen**  
**Interface RS-232**  
**pour balances BD**



# Installation

1

## Preparation

- Disconnect balance from power supply.
- Remove weighing pan, except in the BD6000 case.
- Turn balance over.
- Unscrew the four screws of the baseplate. Lift off baseplate.
- Remove cover for connector (1).


## Mounting

- Prepare board (2) with the component side downward. Connector (1) must point to the rear of the balance, connector (3) (on ribbon cable) to the front of the balance.
- Connect connector (3) to main board.
- Install board so that connector (1) is positioned in the opening at the rear.
- Screw the self-tapping screws through the board into the body of the balance.

### Caution

Do not strip the screw threads.

- Fasten baseplate using the four screws.
- Turn balance over and replace weighing pan.



# Einbau

2

## Vorbereitung

- Waage vom Netz trennen.
- Waagschale entfernen, ausser bei BD6000.
- Waage umdrehen.
- Die vier Schrauben der Bodenplatte herausdrehen. Bodenplatte abheben.
- Abdeckung für Stecker (1) entfernen.


## Montage

- Die Platine (2) mit der bestückten Seite nach unten zurechtlegen. Stecker (1) muß zur Rückseite der Waage, Stecker (3) (am Flachbandkabel) zur Vorderseite der Waage zeigen.
- Stecker (3) mit der Hauptplatine verbinden.
- Platine so einbauen, daß sich Stecker (1) in der Öffnung an der Rückseite befindet.
- Die selbstschneidenden Schrauben durch die Platine in den Waagenkorpus einschrauben.

### Achtung

Schrauben nicht überdrehen.

- Bodenplatte mit den vier Schrauben befestigen.
- Waage umdrehen und Waagschale aufsetzen.



# Montage

3

## Préparation

- Débrancher la balance du secteur.
- Retirer le plateau, sauf sur le modèle BD6000.
- Poser la balance à l'envers.
- Dévisser les 4 vis de la plaque de base. Retirer la plaque de base.
- Retirer le cache du connecteur (1).


## Montage

- Mettre la carte en place, côté composants vers le bas. Le connecteur (1) doit être orienté vers la face arrière de la balance et le connecteur (3) (du câble en nappe) vers la face avant.
- Relier le connecteur (3) avec la carte principale.
- Monter la carte de telle sorte que le connecteur (1) soit engagé dans l'ouverture prévue sur la face arrière.
- Visser les vis autotaraudeuses à travers la carte dans le corps de la balance.

### Attention

Ne pas forcer le pas de vis.

- Fixer la plaque de base à l'aide des quatre vis.
- Remettre la balance sur ses pieds et poser le plateau.



# Technical data

## RS-232C interface

Interface type	voltage-controlled interface following EIA RS-232C/DIN 66020 (CCITT V.24/V.28)
Mode	full duplex
Transmission mode	bit-serial, asynchronous (1 start bit)
Transmission code	7-bit code, ASCII-ISO 464 + parity bit
Baud rate	300, 1200, 2400, 4800, 9600
Parity	even, odd, none, space
Stop bit	1 (receiving), 2 (transmitting)

# Connection


## Cables

Prepared connection cables are available for the following devices:

	Order number
Printer Epson P-40	33688
Computer Epson PX-4	33982
Computer Epson HX-20	33955
Computer Apple Macintosh	210495

When using these cables, only the interface parameters have to be configured in the menu (see page 6).


Additional cables and connectors:



	Order number
Cable set, 25-pin male, for printer	210492
Cable set, 25-pin female, for IBM XT/PS2 etc.	210491
Cable set, 9-pin female, for IBM AT/laptops etc.	210493
Extension cable DATA I/O, 5 m	216152
MiniMettler connector, solderable	33930

# Connection

## Pin assignment



The balance has the following connector pin assignment:


11	green	Commands for balance	RXD
6	brown	Data from balance	TXD
1	white	Signal ground	GND
13	yellow	Handshake to balance	DTR
3	grey	Handshake from balance	CTS

## Handshake



In operation of the RS-232 interface, the data transmission can be controlled by a mutual exchange of ready messages (handshake). In an uncontrolled data transmission (free mode), data losses can appear.

## Handshake modes




- **Software handshake**

The control signals (Xon/Xoff) are transmitted like data using the transmitting and receiving line.

- **Hardware handshake**

The control signals are transmitted along additional control lines.



**Note**

The commands "S" and "SI" (single inquiry) also control the data transmission. This informs the computer that it must again request a result.

# Configuration in the menu

6

---

The interface parameters of the balance must be matched to these of the peripheral instruments.

This section describes the menu settings that concern the interface. Operation in the menu is described in the operating instructions of the BD balances.

---

## Transmission mode

<b>5.5tb</b>	<b>Send stable</b>	send next stable weighing result, triggering by  key (factory setting)
<b>5.RLL</b>	<b>Send All</b>	send current value (stable or not), triggering by  key
<b>5.Auto</b>	<b>Send Auto</b>	send stable values after every change (> 5 d)
<b>5.Cont</b>	<b>Send continuous</b>	send all values continuously; maximum rate is the clock pulse of the display (every 0.2 seconds). If the selected baud rate is too low, values can be lost.

---

## Transmission rate (baud rate)

<b>b 300</b>	300 baud
<b>b 1200</b>	1200 baud
<b>b 2400</b>	<b>2400 baud</b> (factory setting)
<b>b 4800</b>	4800 baud
<b>b 9600</b>	9600 baud

---

## Parity

<b>P -E-</b>	<b>even</b> (factory setting)
<b>P -0-</b>	odd
<b>P -n-</b>	none
<b>P -S-</b>	space

# Command set

---

## Entry of commands

---

No distinction is made between upper- and lowercase letters.  
Each command must be closed with  $C_R L_F$ .



Commands that can not be executed immediately are overwritten by those that follow, i.e. they are lost.

If the balance can not execute or evaluate a command, it sends an appropriate error message.

---

## Send next stable weighing result

---

Command: S (Send value)

Format: S | C<sub>R</sub> | L<sub>F</sub>

Note: On stability, the current weighing result is sent immediately.

Example:

**Computer:**

S | C<sub>R</sub> | L<sub>F</sub>

**Balance:**

Stability

S | \_ | \_ | \_ | \_ | \_ | 9 | 5 | . | 3 | 7 | \_ | g | C<sub>R</sub> | L<sub>F</sub>

---

## Send current weighing result

---

Command: SI (Send Immediate value)

Format: S | I | C<sub>R</sub> | L<sub>F</sub>

Note: The balance sends the current weighing result immediately. Unstable weighing results are marked with "D" (dynamic).

Example:

**Computer:**

S | I | C<sub>R</sub> | L<sub>F</sub>

**Balance:**

S | D | \_ | \_ | \_ | \_ | 9 | 5 | . | 3 | 7 | \_ | g | C<sub>R</sub> | L<sub>F</sub>

or on stability

S | \_ | \_ | \_ | \_ | 1 | 0 | 0 | . | 3 | 0 | \_ | g | C<sub>R</sub> | L<sub>F</sub>

# Command set

---

## Send current weighing result repeatedly

---

Command: SIR (Send Immediate value and Repeat)

Format: S | I | R | C<sub>R</sub> | L<sub>F</sub>

Note: The balance sends the current weighing result and then all others; maximum rate is the clock pulse of the display (every 0.2 seconds). If the baud rate has not been matched to this maximum rate, values can be lost.

Example:

**Computer:**

S | I | R | C<sub>R</sub> | L<sub>F</sub>

S | D | \_ | \_ | \_ | \_ | 9 | 5 | . | 3 | 7 | \_ | g | C<sub>R</sub> | L<sub>F</sub>

S | D | \_ | \_ | \_ | \_ | 9 | 5 | . | 4 | 2 | \_ | g | C<sub>R</sub> | L<sub>F</sub>

S | D | \_ | \_ | \_ | \_ | 9 | 5 | . | 4 | 1 | \_ | g | C<sub>R</sub> | L<sub>F</sub>

S | \_ | \_ | \_ | \_ | 9 | 5 | . | 4 | 0 | \_ | g | C<sub>R</sub> | L<sub>F</sub>

---

## Taring balance

---

Command: T (Tare)

Format: T | C<sub>R</sub> | L<sub>F</sub>

Notes: With this command, taring can be accomplished via the interface. If no stability is found within 10 seconds, an error message "EL" is outputted.  
If taring can not be performed owing to overload or underload, "EL" is outputted immediately.  
If an "SI" or "SIR" command follows a "T" command and the balance is waiting for stability, it sends the error message "SI".

Example:

**Computer:**

T | C<sub>R</sub> | L<sub>F</sub>

Balance: There is no acknowledgement via the interface.

# Command set

## Calling up balance identification

Command: ID (Identify)  
 Format: 

I	D	C <sub>R</sub>	L <sub>F</sub>
---	---	----------------	----------------

Note: The balance sends its identification in the following format:

Example: **Computer:**

I	D	C <sub>R</sub>	L <sub>F</sub>
---	---	----------------	----------------

**Balance:**

B	D	2	0	2	_	_	1	_	1	2	3	4	5	6	7	C <sub>R</sub>	L <sub>F</sub>
---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	----------------	----------------

  
 Model              Version Identification

# Data output format

Every valid weighing result is outputted in a uniform format. It can be divided into three blocks and is always closed by the string delimiter carriage return and line feed (C<sub>R</sub>L<sub>F</sub>).

Identification of the value 2 characters	– (hex 20)	Weighing result 9 characters right-aligned	– (hex 20)	Unit 1 - 3 characters left-aligned	C <sub>R</sub> L <sub>F</sub>
--	---------------	--	---------------	--	-------------------------------

Identification	Meaning		
<table border="1" style="display: inline-table; vertical-align: middle;"><tr><td>_</td><td>_</td></tr></table>	_	_	Triggering via balance key  , stable value
_	_		
<table border="1" style="display: inline-table; vertical-align: middle;"><tr><td>_</td><td>D</td></tr></table>	_	D	Triggering via balance key  , dynamic value (only with "S.All" configuration)
_	D		
<table border="1" style="display: inline-table; vertical-align: middle;"><tr><td>S</td><td>_</td></tr></table>	S	_	Triggering via interface or transmission mode "S.Cont", stable value
S	_		
<table border="1" style="display: inline-table; vertical-align: middle;"><tr><td>S</td><td>D</td></tr></table>	S	D	Triggering via interface or transmission mode "S.Cont", dynamic value
S	D		

Example: 

S	D	_	_	_	_	-	2	4	.	3	7	_	g	C <sub>R</sub>	L <sub>F</sub>
---	---	---	---	---	---	---	---	---	---	---	---	---	---	----------------	----------------

  
 Dynamic weight value inquiry via the interface

# Data output format

## Status messages of the balance

If the balance can not transmit a valid weighing result, it sends a status message.

### Message

#### Triggering by key

<code> _ I   C<sub>R</sub>   L<sub>F</sub></code>	invalid measurement result
<code> _ I   +   C<sub>R</sub>   L<sub>F</sub></code>	overload
<code> _ I   -   C<sub>R</sub>   L<sub>F</sub></code>	underload

#### Triggering by command or transmission mode "S.Cont"

<code>S   I   C<sub>R</sub>   L<sub>F</sub></code>	invalid measurement result
<code>S   I   +   C<sub>R</sub>   L<sub>F</sub></code>	overload
<code>S   I   -   C<sub>R</sub>   L<sub>F</sub></code>	underload

---

## Error messages

<code>E   S   C<sub>R</sub>   L<sub>F</sub></code>

#### Syntax Error

A command is wrong.

<code>E   L   C<sub>R</sub>   L<sub>F</sub></code>

#### Logical Error

A received command can not be executed.

---

**To protect your METTLER TOLEDO product's future:  
METTLER TOLEDO service assures the quality, measuring  
accuracy and preservation of value of all METTLER TOLEDO  
products for years to come.  
Please send for full details about our attractive terms of  
service.  
Thank you.**



\*P709111\*

Subject to technical changes and to the availability  
of the accessories supplied with the instruments.

© Mettler-Toledo GmbH 1998      709111A Printed in Switzerland 9807/2.12

**Mettler-Toledo GmbH**, CH-8606 Greifensee, Switzerland  
Phone +41-1-944 22 11, Fax +41-1-944 30 60, Internet: <http://www.mt.com>