



DigiTOL® POWERCELL®

Vehicle Scale Load Cell

**Provides Superior Performance
to Conventional Analog Load Cells**

METTLER TOLEDO





Easy access to the POWERCELL load cell.

Bottom Line – You Get More Reliable Uptime with DigiTOL POWERCELL Load Cells

External influences can wreak havoc on your vehicle scales and result in expensive downtime. Low voltage analog signals, radio frequency interference (RFI), moisture and corrosion, off-center loads, non-linearity and temperature changes all affect the accuracy and dependability of your vehicle scale load cells.

The METTLER TOLEDO POWERCELL load cell has years of proven performance and the largest installed base of heavy industrial digital load cells in the world to back it up. The result is that you have more uptime and reduced maintenance costs. Each POWERCELL load cell has built-in self-diagnostics

that constantly monitor the cell's performance and automatically correct for external factors.

The DigiTOL POWERCELL load cell has been developed to provide accurate and reliable weight every time and to withstand the effects of external factors. The chart below outlines the features we have designed into our load cells to ensure that you get the performance you expect from a METTLER TOLEDO vehicle scale.

Ease of Maintenance

When maintenance is required, the process is simplified. The indicator displays an error code that details the problem and pinpoints the cell location. Diagnosis and replacement, if necessary, is quick; cables are removable so there is no need to replace them. Test weights aren't always necessary because of calibration constants, and your vehicle scale is back in service before you know it.

Proven Performance

Capacities are 22.5 metric tonnes/50,000 lb, 45 metric tonnes/100,000 lb, and 90 metric tonnes/200,000 lb. Over 500,000 POWERCELL load cells are in use worldwide. This represents the largest installed base of digital heavy industrial load cells in the world.

For more information on the POWERCELL load cell, call your nearest METTLER TOLEDO office or nearest authorized distributor. Or visit our web site: www.mt.com.



POWERCELL load cells withstand the extreme conditions in Antarctica.

Produced in a facility that is



| External Effect | Solution | Proof |
|------------------------------|--|---|
| LIGHTNING | StrikeShield | <h2>500,000 POWERCELL Load Cells Installed Worldwide</h2> |
| Temperature | On-Board Microprocessor | |
| TIME LOAD SEQUENCE | On-Board Microprocessor | |
| RADIO FREQUENCY INTERFERENCE | Powerful Digital Signal | |
| Corrosion | Stainless Steel Hermetically Sealed Construction | |
| Moisture | Glass-to-Metal Connectors | |

METTLER TOLEDO

USA
1900 Polaris Parkway
Columbus, Ohio 43240
TEL. (800) 523-5123
(614) 438-4511
FAX (614) 438-4900

Headquarters
8606 Greifensee
Switzerland

TEL. (41-1) 944 22 11
FAX (41-1) 944 30 60

| | TEL | FAX | | TEL | FAX |
|----------------|--------------------|--------------------|-----------------|-------------------|-------------------|
| Australia | (61-3) 9644 5700 | (61-3) 9645 3935 | Korea | (82-2) 3498-3500 | (82-2) 3498-3555 |
| Austria | (43-1) 604 1980 | (43-1) 604 2880 | Malaysia | (60-3) 7845 5773 | (60-3) 7845-8773 |
| Belgium | (32-2) 334 0211 | (32-2) 334 0334 | Mexico | (52-5) 547 5700 | (52-5) 541 2228 |
| Brazil | (55-11) 4166-7400 | (55-11) 4166-7401 | Netherlands | (31-344) 638363 | (31-344) 638390 |
| Canada | (800) 638-8537 | (905) 681-8036 | Norway | (47) 22 30 44 90 | (47) 22 32 70 02 |
| China | (86-519) 6642040 | (86-519) 6641991 | Poland | (48-22) 651-9232 | (48-22) 651-7172 |
| Croatia | (385-1) 29 58 130 | (385-1) 29 58 140 | Russia | (7-095) 921 9211 | (7-095) 921 6353 |
| Czech Republic | (420-2) 721-23150 | (420-2) 721-23170 | Singapore | (65) 6890 0011 | (65) 6890 0012 |
| Denmark | (45-43) 27 08 00 | (45-43) 27 08 28 | Slovak Republic | (421-2) 4342-7496 | (421-2) 4333-7190 |
| France | (33-1) 30 97 17 17 | (33-1) 30 97 16 16 | Slovenia | (386-1) 562-1801 | (386-1) 562-1789 |
| Germany | (49-641) 50 70 | (49-641) 52951 | Spain | (34-93) 223-7600 | (34-93) 223-0271 |
| Hungary | (36-1) 288-4040 | (36-1) 288-4050 | Sweden | (46-8) 702 50 00 | (46-8) 642 45 62 |
| India | (91-22) 2857-0808 | (91-22) 2857-5071 | Switzerland | (41-1) 944 45 45 | (41-1) 944 45 10 |
| Italy | (39-02) 333321 | (39-02) 356-2973 | Taiwan | (886-2) 2657-8898 | (886-2) 2657-0776 |
| Japan | (81-3) 5762-0606 | (81-3) 5762-0756 | Thailand | (66-2) 723-0300 | (66-2) 719-6479 |
| Kazakhstan | (7-3272) 50 63 69 | (7-3272) 98 08 35 | United Kingdom | (44-116) 235 7070 | (44-116) 236 6399 |

Internet
www.mt.com

Specifications subject to change without notice.
© 1999 Mettler-Toledo, Inc.

METTLER TOLEDO®, DigiTOL®, POWERCELL® and StrikeShield are trademarks of Mettler-Toledo, Inc. Printed on recycled paper and is recyclable.

Printed in USA.

01-2011
TRUCK SCALES
199-GL03184.1E