

Packing list

Demo Case ErgoClip Weighing solution Kit

Layer 1

Position	Designation	Part No.
A	Spatula*	
B	ErgoClip filter holder (without holder)	11140185
C	ErgoClip Tube	11106784
D	ErgoClip Holder	
E	Eppendorf tube 1.5 ml*	
E	Eppendorf tube 0.5 ml*	
E	1 HPLC vial – crimple*	
E	1 HPLC vial – screw caps*	
F	Space for weighing sample (Salt [NaCl], 125 g*)	
G	Vial Adapters Ø 10.3 mm / 12 mm / 15 mm / 16.2 mm / 21 mm	
H	ErgoClip Quantos	11141570
I	Picture Frame – Sapphire DPF-080*	
I	Memory stick, 1GB*	

* Items are not available at METTLER TOLEDO



Layer 2


Position	Designation	Part No.
J	Ergo Clip Round Bottom Flask	11106746
J	Smart Grid	11106333
K	Ergoclip Small Flask (without holder)	11140180
L	ErgoClip Weighing Boat	11106748
L	Weighing boats (10 piece)	11106712
M	ErgoClip Titration Basket	11106883
N	ErgoClip Flask (without holder)	11106764
O	Volumetric flask 10 ml*	
P	Volumetric flask 100 ml*	
Q	Reagenz glass small*	
R	ErgoClip Basket Small	11106747
S	Round bottom flask 50 ml*	
T	Min Weigh door	11106749

* Items are not available at METTLER TOLEDO



Layer 3

Position	Designation	Part No.
U	Stand large	11140170
V	Tweezer	00210421




Quick guide for using the photo frame

- 1** Remove the frame and assemble the stand on the backside.



- 2** Connect the power cable (1) and switch on the frame (2).



- Connect the USB Stick
- Choose the menu "Movie" (1) on the screen by pressing the arrow buttons (2) on the remote control.

- 4**
- Press ENTER and select the appropriate movie (only MPEG, DAT or AVI)
 - Press ENTER: The movie starts
 - During the movie: Press green MENU button on the remote control and you see a menu bar on the screen. You can pause, move fast forward or backward or stop the movie.



Note:

The picture frame may react slowly. Please hold the remote control **close to the picture frame** at the bottom side.