



UWT™

Unattended Weighing Terminal

Inbound/Outbound



Weigh Vehicles Inbound/Outbound In Attended or Unattended Operations

METTLER TOLEDO



UWT™ Weighing Terminal for Unattended Operation

The METTLER TOLEDO® Unattended Weighing Terminal (UWT) allows you to weigh vehicles and capture information 24 hours per day, 7 days per week, without a scale operator being present. The UWT™ can be configured to meet application specific requirements. Available options include:

- Proximity badge reader that allows operators to identify themselves, providing facility access control when used with gates
- Thermal printer that provides the driver with a weight ticket
- Intercom that allows the driver to speak with the scale house or office
- Loop detectors to control traffic in bi-directional operation
- I/O for control of peripheral equipment

The UWT™ includes the industry leading JAGXTREME scale instrument, which interfaces to both analog and digital scales. The JAGXTREME's advanced communication capabilities allow for fast, simple communication via an ethernet port.

The METTLER TOLEDO VSX Inbound/Outbound Vehicle Weighing Software comes preloaded on the UWT™. User-configurable registers allow for entry of vehicle or driver ID numbers, RFID badge information, tare weights, and commodity types.

Transaction and commodity reports can be printed locally, or transmitted via ethernet to remote PC's, for simple import into a variety of financial or database programs.



Typical applications include:

- Pulpwood processors
- Feed mills
- Steel processors
- Aggregates
- Landfills
- Chemical plants

Optional METTLER TOLEDO® Axle Vehicle Scale software can be used for axle scale installations. Typical applications include trucking terminals where the scale terminal is interfaced to a traffic light that directs the driver. The individual axle weights are displayed on a scoreboard or printed on an outbound ticket. Compliance with over-the-road legal load limits is verified.

Attended Operation

For attended weighing the METTLER TOLEDO JAGXTREME scale terminal comes pre-loaded with the METTLER TOLEDO VSX Inbound/Outbound Vehicle Weighing Software.

Optional traffic lights or gates can be connected to the JAGXTREME for signaling drivers when the scale is ready for weighing, and when the weighing process has been completed.


For applications requiring both attended and unattended weighing, the UWT™ can be connected to a JAGXTREME operator interface (JXOI) unit located in the scale house. This allows scale house personnel to operate the scale during high volume periods, and the driver to operate the scale via the UWT™ during lower volume periods.



JAGXTREME Scale Terminal



JXOI Terminal



TEL

FAX

TEL

FAX

METTLER TOLEDO

USA

1900 Polaris Parkway
Columbus, Ohio 43240
TEL. (800) 523-5123
(614) 438-4511
FAX (614) 438-4900

Latin America

TEL. (01) 305-351-2424
FAX (01) 305-351-2425

Headquarters

8606 Greifensee
Switzerland
TEL. (41-1) 944 22 11
FAX (41-1) 944 30 60

Australia	(61-3) 9644 5700
Austria	(43-1) 604 1980
Belgium	(32-2) 334 0211
Brazil	(55-11) 4166-7400
Canada	(800) 638-8537
China, Shanghai	(86-21) 6485 0435
China, Changzhou	(86-519) 664 2040
China, Hong Kong	(852) 2744 1221
Croatia	(385-1) 29 58 130
Czech Republic	(420-2) 721-23150
Denmark	(45-43) 27 08 00
France	(33-1) 30 97 17 17
Germany	(49-641) 50 70
Hungary	(36-1) 288-4040
India	(91-22) 2857-0808
Indonesia	(62-21) 6583 3731
Italy	(39-02) 333321
Japan	(81-3) 5762-0606

(61-3) 9645 3935
(43-1) 604 2880
(32-2) 334 0334
(55-11) 4166-7401
(905) 681-8036
(86-21) 6485 3351
(852) 2744 6878
(86-519) 664 1991
(45-43) 27 08 28
(33-1) 30 97 16 16
(49-641) 52951
(36-1) 288-4050
(91-22) 2857-5071
(62-21) 6583 3741
(39-02) 356-2973
(81-3) 5762-0756

Kazakhstan	(7-3272) 50 63 69
Korea	(82-2) 3498-3500
Malaysia	(60-3) 7845 5773
Mexico	(52-5) 547 5700
Netherlands	(31-344) 638363
Norway	(47) 22 30 44 90
Philippines	(63-2) 864 1600
Poland	(48-22) 651-9232
Russia	(7-095) 921 9211
Singapore	(65) 6890 0011
Slovak Republic	(421-2) 4342-7496
Slovenia	(386-1) 562-1801
Spain	(34-93) 223-7600
Sweden	(46-8) 702 50 00
Switzerland	(41-1) 944 45 45
Taiwan	(886-2) 2579-5955
Thailand	(66-2) 723-0300
United Kingdom	(44-116) 235 7070

(7-3272) 98 08 35
(82-2) 3498-3555
(60-3) 7845-8773
(52-5) 541 2228
(31-344) 638390
(47) 22 32 70 02
(63-2) 864 1698
(48-22) 651-7172
(7-095) 921 6353
(65) 6890 0012
(421-2) 4333-7190
(386-1) 562-1789
(34-93) 223-0271
(46-8) 642 45 62
(41-1) 944 45 10
(886-2) 2579-5977
(66-2) 719-6479
(44-116) 236 6399

Internet

www.mt.com

Specifications and other information subject to change without notice.

©2003 Mettler-Toledo Inc.

METTLER TOLEDO® is a registered trademark of Mettler-Toledo Inc. All other brand of product names are trademarks of their respective companies.

Printed in USA

03M0103

IN03400.0E